Mandis shop

Pioneer CU-DC014

Original	Rechange	Original	Rechange
Power	Power	Stop CD	Stop / Hold
Phono	Smart / List	Disc	Blue / Prime Video / Random
Volume-	Vol -	Play CD	Play / Slow
Volume+	Vol +	Snooze	Display / Media
Tuner Station-	CH- / Page-	Pause CD	Pause / Step / Freeze
Tuner Station+	CH+ / Page+	I<< Track Search	I<< / Preset-
< Play Deck II	+ Shift + Left	Track Search >>I	>>I / Preset+
Play > Deck II	+ Shift + Right		
< Play Deck I	Left		
Play > Deck I	Right		
<< Fast Deck I	<< / Tune-		
Fast >> Deck I	>> / Tune+		
Stop Deck I	OK		
Rec Deck II	Rec / Rec Mode		
Pause Deck II	+ Shift + Pause / Step /		
Stop Deck II	+ Shift + Stop /		
Timer Sleep	Sleep / Timer		

https://remote-controls.ch/fr/Pioneer/16749-582-telecommande-de-remplacement-pour-Pioneer-CU-DC014-AC081.html