Mandis shop

NEVI R013

Original		Rechange	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
L/R	L/R	TITLE SOUND	Sound / Title
LANGUAGE	Language	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
TIME	Time	TIMER SLEEP	Sleep / Timer
TV/RADIO	TV/Radio	PROGRAM TV/RADIO	TV/Radio / Program

Original		Rechange	
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
TITLE/TTX	Title/TTX	GOTO TEXT	Text / Goto
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
MENU/PBC	Menu/PBC	HOME MENU	Menu / Home
UP	Up		Up
FAV-	Left/FAV-		Left
ENTER	Enter	OK	OK
FAV+	Right/FAV+		Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
DOWN	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOL+	Vol +	+ VOL	Vol +
N/P	N/P	LIST SMART	Smart / List
VOL-	Vol -	VOL –	Vol -
OSD	OSD	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2

Original		Rechange		Original	Rechange
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
+10	0/10	HDMI - SAT 0	0		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
ANGLE /DEL	Angle/Del	Prime Video RANDOM	Blue / Prime Video / Random		
SLOW	Slow	SHIFT + SLOW ▶	Shift + Play /		
STEP	Step	SHIFT + STEP - FREEZE ⏸	Shift + Pause / Step /		
VIDEO	Video	SHIFT + VIDEO 4	Shift + 4		
PROG/EPG	Prog/EPG	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--		