Mandis shop

RC-601

Original		Rechange	
IN	IN		Up
IN	IN	CH PAGE +	CH+ / Page+
IN	IN		Right
IN	IN	VOL +	Vol+
OUT	OUT		Down
OUT	OUT	CH PAGE −	CH- / Page-
OUT	OUT		Left
OUT	OUT	VOL −	Vol-

Original	Rechange

https://remote-controls.ch/fr/LAVA/1068113-27978-telecommande-de-remplacement-pour-LAVA-RC-601.html