Mandis shop

POLK AUDIO 981307102280K

Original		Rechange	
	Power		Power
1	HDMI 1	TV 1	1
2	HDMI 2	DVD 2	2
3	HDMI 3	CD - STB 3	3
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /
	Bluetooth	BLUETOOTH 9	9
BASS +	Bass+		Up
VOL +	Vol +	VOL +	Vol +
VOICE +	Voice+	CH + PAGE	CH+ / Page+
BASS -	Bass-		Down
VOL -	Vol -	VOL -	Vol -
VOICE -	Voice-	CH - PAGE	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
MOVIE	Movie	EQ SUBTITLE	Subtitle / EQ
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II
NIGHT	Night	CLEAR EXIT CANCEL	Exit / Cancel / Clear
3D	3D	FORMAT PICTURE	Picture / Format

Original		Rechange	
SPORT	Sport	RETURN BACK	Back / Return
VOLUME SURROUND -	Volume Surround-	SHIFT + VOL -	Shift + Vol -
VOLUME SURROUND +	Volume	SHIFT + VOL +	Shift + Vol +
BALANCE L	Balance L		Left
BALANCE R	Balance R		Right

https://remotecontrols.fr/fr/POLK-AUDIO/10617-957-telecommande-de-remplacement-pour-POLK-AUDIO-981307102280K.htm