

Original	Rechange
Tuner	Red / Netflix / Search
CD	Yellow / YouTube / Repeat
Tape	Blue / Prime Video / Random
TV	TV/Radio /
CDV	Zoom / Size
VCR	Green / APP / Repeat
1 TV	1
1 VCR	Shift + 1
2 TV	2
2 VCR	Shift + 2
3 TV	3
3 VCR	Shift + 3
4 TV	4
4 VCR	Shift + 4
5 TV	5
5 VCR	Shift + 5
6 TV	6

Original	Rechange
6 VCR	Shift + 6
7 TV	7
7 VCR	Shift + 7
8 TV	8
8 VCR	Shift + 8
9 TV	9
9 VCR	Shift + 9
Memo TV	Guide / EPG / -/--
Memo VCR	Shift + Guide / EPG / -/--
0 TV	0
0 VCR	Shift + 0
Clear TV	Exit / Cancel / Clear
Clear VCR	Shift + Exit / Cancel / Clear
</A-Scan TV	Left
Mode/Random	Smart / List
P:P/> TV	Right
P:P/> VCR	Shift + Right





Original	Rechange
Preset Up/Red TV	Up
Disc Up/Green TV	CH+ / Page+
Vol+ TV	Vol+
Vol+ VCR	Shift + Vol+
Preset Down/Yellow TV	Down
Disc Down/Blue	CH- / Page-
Vol- TV	Vol-
Vol- VCR	Shift + Vol-
Stop TV	Stop / Hold
Stop VCR	Shift + Stop /
Pause TV	Pause / Step / Freeze
Pause VCR	Shift + Pause / Step /
Play TV	Play / Slow
Play VCR	Shift + Play /
↔ TV	Picture / Format
<< TV	<< / Tune-
<< VCR	Shift + << / Tune-

Original	Rechange
>> TV	>> / Tune+
>> VCR	Shift + >> /
TXT TV	Text / Goto
Rec VCR	Shift + Rec / Rec Mode
STBY TV	Power
STBY VCR	Shift + Power





Original		Rechange	
TUNER	Tuner	NETFLIX SEARCH	Red / Netflix / Search
CD	CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TAPE	Tape	Prime Video RANDOM	Blue / Prime Video / Random
TV	TV	PROGRAM TV/ RADIO	TV/Radio /
CDV	CDV	SIZE ZOOM	Zoom / Size
VCR	VCR	APP REPEAT	Green / APP / Repeat
1	1 CD	TV 1	1
2	2 CD	DVD 2	2
3	3 CD	CD - STB 3	3
4	4 CD	VIDEO 4	4
5	5 CD	TAPE 5	5
6	6 CD	TUNER 6	6
7	7 CD	AUX - HDD 7	7
8	8 CD	USB 8	8
9	9 CD	BLUETOOTH 9	9
MEMO	Memo CD	-/-- GUIDE EPG	Guide / EPG / -/--
0	0 CD	HDMI - SAT 0	0

Original		Rechange	
CLEAR -/--	Clear CD	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MODE RANDOM	Mode/Random	LIST SMART	Smart / List
PRESET	Preset Up CD		Up
DISC	Disc Up CD	CH PAGE +	CH+ / Page+
VOL.	Vol+ CD	VOL +	Vol+
PRESET	Preset Down CD		Down
DISC	Disc Down CD	CH PAGE −	CH- / Page-
VOL.	Vol- CD	VOL −	Vol-
STOP	Stop CD	HOLD	Stop / Hold
PAUSE	Pause CD	STEP - FREEZE	Pause / Step / Freeze
PLAY	Play CD	SLOW	Play / Slow
	↔ CD	FORMAT PICTURE	Picture / Format
	<< CD	TUNE-	<< / Tune-
	>> CD	TUNE+	>> / Tune+
ST.BY	STBY CD		Power





Original		Rechange	
TUNER	Tuner	NETFLIX SEARCH	Red / Netflix / Search
CD	CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TAPE	Tape	Prime Video RANDOM	Blue / Prime Video / Random
TV	TV	PROGRAM TV/RADIO	TV/Radio /
CDV	CDV	SIZE ZOOM	Zoom / Size
VCR	VCR	APP REPEAT	Green / APP / Repeat
1	1 Tuner	TV 1	1
1	1 CDV	SHIFT + TV 1	Shift + 1
2	2 Tuner	DVD 2	2
2	2 CDV	SHIFT + DVD 2	Shift + 2
3	3 Tuner	CD - STB 3	3
3	3 CDV	SHIFT + CD - STB 3	Shift + 3
4	4 Tuner	VIDEO 4	4
4	4 CDV	SHIFT + VIDEO 4	Shift + 4
5	5 Tuner	TAPE 5	5
5	5 CDV	SHIFT + TAPE 5	Shift + 5
6	6 Tuner	TUNER 6	6

Original		Rechange	
6	6 CDV	SHIFT + TUNER 6	Shift + 6
7	7 Tuner	AUX - HDD 7	7
7	7 CDV	SHIFT + AUX - HDD 7	Shift + 7
8	8 Tuner	USB 8	8
8	8 CDV	SHIFT + USB 8	Shift + 8
9	9 Tuner	BLUETOOTH 9	9
9	9 CDV	SHIFT + BLUETOOTH 9	Shift + 9
MEMO	Memo Tuner	-/-- GUIDE EPG	Guide / EPG / -/--
MEMO	Memo CDV	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0	0 Tuner	HDMI - SAT 0	0
0	0 CDV	SHIFT + HDMI - SAT 0	Shift + 0
CLEAR	Clear Tuner	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CLEAR	Clear CDV	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
A-SCAN	</A-Scan Tuner		Left
MODE RANDOM	Mode/Random	LIST SMART	Smart / List
MODE RANDOM	Mode/Random	SHIFT + LIST SMART	Shift + Smart / List
PRESET	Preset Up Tuner		Up





Original	Rechange
Preset Up CDV	SHIFT + Shift + Up
Disc Up CDV	CH+ / Page+
Vol+ Tuner	Vol+
Vol+ CDV	SHIFT + Shift + Vol+
Preset Down	Down
Preset Down	SHIFT + Shift + Down
Disc Down CDV	CH- / Page-
Vol- Tuner	Vol-
Vol- CDV	SHIFT + Shift + Vol-
Stop CDV	SHIFT + Shift + Stop /
Pause CDV	SHIFT + Shift + Pause / Step /
Play CDV	SHIFT + Shift + Play /
↔ CDV	SHIFT + Shift + Picture / Format
<< Tuner	<< / Tune-
<< CDV	SHIFT + Shift + << /
>> Tuner	>> / Tune+
>> CDV	SHIFT + Shift + >> / Tune+

Original	Rechange
STBY Tuner	Power
STBY CDV	SHIFT + Shift + Power





Original		Rechange	
TUNER	Tuner	NETFLIX SEARCH	Red / Netflix / Search
CD	CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TAPE	Tape	Prime Video RANDOM	Blue / Prime Video / Random
TV	TV	PROGRAM TV/RADIO	TV/Radio /
CDV	CDV	SIZE ZOOM	Zoom / Size
VCR	VCR	APP REPEAT	Green / APP / Repeat
1	1 Tape	TV 1	1
2	2 Tape	DVD 2	2
3	3 Tape	CD - STB 3	3
4	4 Tape	VIDEO 4	4
5	5 Tape	TAPE 5	5
6	6 Tape	TUNER 6	6
7	7 Tape	AUX - HDD 7	7
8	8 Tape	USB 8	8
9	9 Tape	BLUETOOTH 9	9
MEMO	Memo Tape	-/-- GUIDE EPG	Guide / EPG / -/--
0	0 Tape	HDMI - SAT 0	0

Original		Rechange	
CLEAR -/--	Clear Tape	CLEAR EXIT CANCEL	Exit / Cancel / Clear
A-SCAN	</A-Scan Tape		Left
MODE RANDOM	Mode/Random	LIST SMART	Smart / List
P.P.	P:P/> Tape		Right
PRESET	Preset Up Tape		Up
VOL.	Vol+ Tape	+ VOL	Vol+
PRESET	Preset Down Tape		Down
VOL.	Vol- Tape	VOL −	Vol-
STOP	Stop Tape	HOLD	Stop / Hold
PAUSE	Pause Tape	STEP - FREEZE	Pause / Step / Freeze
PLAY	Play Tape	SLOW	Play / Slow
	↔ Tape	FORMAT PICTURE	Picture / Format
	<< Tape	TUNE-	<< / Tune-
	>> Tape	TUNE+	>> / Tune+
TXT	TXT Tape	GOTO TEXT	Text / Goto
REC	Rec Tape	REC MODE	Rec / Rec Mode
ST.BY	STBY Tape		Power

