

Original		Rechange	
TV	TV	PROGRAM TV/ RADIO	TV/Radio /
Power	Power	Power	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
CM	CM	RETURN BACK	Back / Return
*	*	HOME MENU	Menu / Home
#[>☰]	#[>☰]	PC FAV MARKER	Fav / Marker / PC
Call	Call	EQ SUBTITLE	Subtitle / EQ

Original		Rechange	
i	i	ANGLE INFO	Info / Angle
[__]/[☰>]	[__]/[☰>]	CLEAR EXIT CANCEL	Exit / Cancel / Clear
[☰][+]	[☰][+]	OPT-TOOLS SETUP	Setup / OPT /
[*]	[*]	FORMAT PICTURE	Picture / Format
[/][☰]	[/][☰]	SIZE ZOOM	Zoom / Size
[ ]00:00	[ ]00:00	NETFLIX SEARCH	Red / Netflix / Search
←>	←>	MEDIA DISPLAY	Display / Media
→>	→>	LIST SMART	Smart / List
[☰]	[☰]	GOTO TEXT	Text / Goto
x(→←)	x(→←)	LANG I/II AUDIO	Audio / Lang I/II
→º→	→º→	TOP MENU D.MENU	D.Menu / Top
Mute	Mute	DIMMER MUTE	Mute / Dimmer
Brightness-	Brightness-		Left
Brightness+	Brightness+		Right
(♪)	(♪)	TITLE SOUND	Sound / Title
Color-	Color-		Down
Color+	Color+		Up





Original	Rechange	Original	Rechange
(<>)	Sleep / Timer		
Vol-	Vol-		
Vol+	Vol+		
1/2	Eject / Surround		
Pause	Pause / Step / Freeze		
Play	Play / Slow		
Rec	Rec / Rec Mode		
<<	<< / Tune-		
Stop	Stop / Hold		
>>	>> / Tune+		





Original		Rechange	
TV	TV	PROGRAM TV/RADIO	TV/Radio /
Power	Power	Power	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
CM	CM	RETURN BACK	Back / Return
*	*	HOME MENU	Menu / Home
#[>☰]	#[>☰]	PC FAV MARKER	Fav / Marker / PC
Call	Call	EQ SUBTITLE	Subtitle / EQ

Original		Rechange	
i	i	ANGLE INFO	Info / Angle
[__]/[☰>]	[__]/[☰>]	CLEAR EXIT CANCEL	Exit / Cancel / Clear
[☰][+]	[☰][+]	OPT-TOOLS SETUP	Setup / OPT /
[*]	[*]	FORMAT PICTURE	Picture / Format
[/][☰]	[/][☰]	SIZE ZOOM	Zoom / Size
[ ]00:00	[ ]00:00	NETFLIX SEARCH	Red / Netflix / Search
←>	←>	MEDIA DISPLAY	Display / Media
→>	→>	LIST SMART	Smart / List
[☰]	[☰]	GOTO TEXT	Text / Goto
x(→←)	x(→←)	LANG I/II AUDIO	Audio / Lang I/II
→º→	→º→	TOP MENU D.MENU	D.Menu / Top
Mute	Mute	DIMMER MUTE	Mute / Dimmer
Brightness-	Brightness-	Left	Left
Brightness+	Brightness+	Right	Right
(♪)	(♪)	TITLE SOUND	Sound / Title
Color-	Color-	Down	Down
Color+	Color+	Up	Up





Original		Rechange		Original		Rechange
	(<>)	TIMER SLEEP	Sleep / Timer			
	Vol-	VOL −	Vol-			
	Vol+	+ VOL	Vol+			
	1/2	SURROUND	Eject / Surround			
	Pause	STEP - FREEZE	Pause / Step / Freeze			
	Play	SLOW	Play / Slow			
	Rec	REC MODE	Rec / Rec Mode			
	<<	TUNE-	<< / Tune-			
	Stop	HOLD	Stop / Hold			
	>>	TUNE+	>> / Tune+			





Original		Rechange	
TV	TV	PROGRAM TV/RADIO	TV/Radio /
Power	Power	Power	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
CM	CM	RETURN BACK	Back / Return
*	*	HOME MENU	Menu / Home
#[>☰]	#[>☰]	PC FAV MARKER	Fav / Marker / PC
Call	Call	EQ SUBTITLE	Subtitle / EQ

Original		Rechange	
i	i	ANGLE INFO	Info / Angle
[__]/[☰>]	[__]/[☰>]	CLEAR EXIT CANCEL	Exit / Cancel / Clear
[☰][+]	[☰][+]	OPT-TOOLS SETUP	Setup / OPT /
[*]	[*]	FORMAT PICTURE	Picture / Format
[/][☰]	[/][☰]	SIZE ZOOM	Zoom / Size
[ ]00:00	[ ]00:00	NETFLIX SEARCH	Red / Netflix / Search
←>	←>	MEDIA DISPLAY	Display / Media
→>	→>	LIST SMART	Smart / List
[☰]	[☰]	GOTO TEXT	Text / Goto
x(→←)	x(→←)	LANG I/II AUDIO	Audio / Lang I/II
→º→	→º→	TOP MENU D.MENU	D.Menu / Top
Mute	Mute	DIMMER MUTE	Mute / Dimmer
Brightness-	Brightness-		Left
Brightness+	Brightness+		Right
(♪)	(♪)	TITLE SOUND	Sound / Title
Color-	Color-		Down
Color+	Color+		Up





Original		Rechange		Original		Rechange
	(<>)	TIMER SLEEP	Sleep / Timer			
	Vol-	VOL −	Vol-			
	Vol+	+ VOL	Vol+			
	1/2	SURROUND	Eject / Surround			
	Pause	STEP - FREEZE	Pause / Step / Freeze			
	Play	SLOW	Play / Slow			
	Rec	REC MODE	Rec / Rec Mode			
	<<	TUNE-	<< / Tune-			
	Stop	HOLD	Stop / Hold			
	>>	TUNE+	>> / Tune+			





Original		Rechange	
TV	TV	PROGRAM TV/RADIO	TV/Radio /
Power	Power	Power	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
CM	CM	RETURN BACK	Back / Return
*	*	HOME MENU	Menu / Home
#[>☰]	#[>☰]	PC FAV MARKER	Fav / Marker / PC
Call	Call	EQ SUBTITLE	Subtitle / EQ

Original		Rechange	
i	i	ANGLE INFO	Info / Angle
[__]/[☰>]	[__]/[☰>]	CLEAR EXIT CANCEL	Exit / Cancel / Clear
[☰][+]	[☰][+]	OPT-TOOLS SETUP	Setup / OPT /
[*]	[*]	FORMAT PICTURE	Picture / Format
[/][☰]	[/][☰]	SIZE ZOOM	Zoom / Size
[ ]00:00	[ ]00:00	NETFLIX SEARCH	Red / Netflix / Search
←>	←>	MEDIA DISPLAY	Display / Media
→>	→>	LIST SMART	Smart / List
[☰]	[☰]	GOTO TEXT	Text / Goto
x(→←)	x(→←)	LANG I/II AUDIO	Audio / Lang I/II
→º→	→º→	TOP MENU D.MENU	D.Menu / Top
Mute	Mute	DIMMER MUTE	Mute / Dimmer
Brightness-	Brightness-		Left
Brightness+	Brightness+		Right
(♪)	(♪)	TITLE SOUND	Sound / Title
Color-	Color-		Down
Color+	Color+		Up





Original	Rechange	Original	Rechange
(<>)	Sleep / Timer		
Vol-	Vol-		
Vol+	Vol+		
1/2	Eject / Surround		
Pause	Pause / Step / Freeze		
Play	Play / Slow		
Rec	Rec / Rec Mode		
<<	<< / Tune-		
Stop	Stop / Hold		
>>	>> / Tune+		

