Original	Rechange	Original	Rechange
Standby / On	Power	Up	Up
Setup	Setup / OPT /	OK	OK
Audio	Audio / Lang I/II	Left	Left
Subtitle	Subtitle / EQ	Right	Right
Angle	Info / Angle	Stop	Stop / Hold
Repeat	Green / APP / Repeat	Down	Down
A-B Repeat	Yellow / YouTube / Repeat	Play	Play / Slow
I<< Skip	I<< / Preset-	<<	<< / Tune-
Clear	Exit / Cancel / Clear	Pause	Pause / Step / Freeze
Skip >>I	>>I / Preset+	>>	>> / Tune+
Title	Sound / Title	1	1
Mode	Smart / List	2	2
Return	Back / Return	3	3
DVD	SHIFT + 2	4	4
Display	Display / Media	5	5
VCR	SHIFT + 4	6	6
Disc Menu	D.Menu / Top Menu	7	7

Original		Rechange	
8	8	8	8
9	9	9	9
+10	+10	GUIDE EPG	Guide / EPG / -/--
0	0	0	0
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SEARCH MODE	Search Mode	NETFLIX SEARCH	Red / Netflix / Search

Original	Rechange

Original	Rechange	Original	Rechange
Timer Set	EQ SUBTITLE — Subtitle / EQ	REW <<	TUNE- << / Tune-
Standby / On	Power	PAUSE Pause	STEP-FREEZE Pause / Step / Freeze
Rec	REC MODE — Rec / Rec Mode	FF >>	TUNE+ >> / Tune+
P-	CH PAGE — CH- / Page-	1	TV 1
C. Reset	CLEAR EXIT CANCEL — Exit / Cancel / Clear	2	DVD 2
P+	CH PAGE — CH+ / Page+	3	CD-STB 3
System	TOP MENU D.MENU — D. Menu / Top	Show View	LIST SMART — Smart / List
DVD	SHIFT + DVD 2 — Shift + 2	4	VIDEO 4
Display	MEDIA DISPLAY — Display / Media	5	TAPE 5
VCR	SHIFT + VIDEO 4 — Shift + 4	6	TUNER 6
Menu	HOME MENU — Menu / Home	7	AUX-HDD 7
Up	Up	8	USB 8
Left	Left	9	BLUETOOTH 9
Right	Right	SPEED Speed	FORMAT PICTURE — Picture / Format
STOP Stop	HOLD — Stop / Hold	DAILY WEEKLY +10 Daily/Weekly	TITLE SOUND — Sound / Title
Down	Down	0	HDMI-SAT 0
PLAY Play	SLOW — Play / Slow	SLOW Slow	SHIFT + SLOW — Shift + Play / Slow

Original	Rechange	Original	Rechange
Quick Find	Red / Netflix / Search		
Index Search	Eject / Surround		
Time Search	Audio / Lang I/II		