Mandis shop

RC4390P

Original		Rechange	
Power		Power	
Source		AV	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
TXT		Text	
Lang		Dual	
Mute		Mute	
Home		Menu	
V+		Vol +	

Original		Rechange	
V-		Vol -	
P+		Ch +	
P-		Ch -	
[G]		Guide	
i		Info	
Back		Back	
Exit		Exit	
OK		Ok	
Up		Up	
Down		Down	
Right		Right	
Left		Left	
Netflix		Media	
YouTube		Smart	
Prime Video		Shift + Smart	
☼1		Format	
Red		Red	

Original		Rechange		Original	Rechange
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
	<<		<<		
	Pause		Pause		
	>>		>>		
	Rec	REC MODE	Rec		
	Play	PLAY MODE	Play		
	Stop		Stop		