Original	Rechange	Original	Rechange
Power	Power	3	3
Mute	Mute / Dimmer	4	4
Play	Play / Slow	5	5
[≡]	Text / Goto	6	6
Pause/ [/≡]	Pause / Step / Freeze	7	7
Stop/ [≡+]	Stop / Hold	8	8
Rec/ [≡♦]	Rec / Rec Mode	9	9
<</ [≡o]	<< / Tune-	Menu	Menu / Home
I <</ [≡i]	I << / Preset-	0	0
>>I / [≡?]	>>I / Preset+	Exit	Exit / Cancel / Clear
>>/ [≡x]	>> / Tune+	Up	Up
P. Mode	Picture / Format	Left	Left
S. Mode	Sound / Title	OK	OK
ANT	D. Menu / Top	Right	Right
Tools	Setup / OPT /	Down	Down
1	1	Back	Back / Return
2	2	Home/ Source	Shift + Menu / Home

Original	Rechange	Original	Rechange
Vol +	Vol +		
APPS	Shift + Green / APP /		
P+	CH+ / Page+		
Vol -	Vol -		
P-	CH- / Page-		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
EPG	Guide / EPG / -/--		
List	Smart / List		
FAV	Fav / Marker / PC		