Mandis shop

9CDM049500

Original		Rechange	
POWER	Power		Power
OPEN /CLOSE	Open/Close	ZOOM	Eject
DVD TV SYS	DVD	A	Red
TUNER	Tuner	B	Green
VIDEO	Video	C	Yellow
TV/AUX	TV/AUX	D	Blue
SLEEP	Sleep	PROG SLEEP	Sleep
	I <<	K<	I <<
	<<	<<	<<
	>>	>>	>>
	>>I	>>I	>>I
PLAY	Play	PLAY MODE	Play
STOP	Stop		Stop
	SP. Setup	APP MEDIA	Media
	CH- Level	-/-- GUIDE	Guide
	SR. Mode	DISC NAV LIST	List
	Title	DISPLAY INFO	Info

Original		Rechange	
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
VOL	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
SET UP	Setup	SETTINGS OPT	Options
PAUSE/STEP	Pause/Step	II	Pause
MENU/RETURN	Menu/Return	TOP MENU MENU	Menu
GO TO AUTO MEMORY	Goto Auto	RETURN BACK	Back
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5

Original		Rechange	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DISP/FM MODE	DISP/FM mode	SEARCH TV/R	TV/R
DELAY TIME	Delay Time	CLEAR EXIT	Exit
TEST TONE	Test Tone	PICTURE FORMAT	Format
SUBTITLE	Subtitle	AD SUBT	Subt
SLOW	Slow	TIMER AV	AV
AUDIO	Audio	SOUND DUAL	Dual
A-B	A-B	HOME SMART	Smart
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
ANGLE	Angle	ECO 3D	3D
RANDOM	Random	E-MANUAL D.MENU	D. Menu
REPEAT	Repeat	REPEAT TEXT	Text
DIGEST RDS MODE	Digest RDS Mode	SHIFT + AD SUBT	Shift + Subt

Original		Rechange	
MPX PTY SEARCH	MPX PTY Search	SHIFT + TIMER AV	Shift + AV
PBC	PBC	SHIFT + SEARCH TV/R	Shift + TV/R