Original		Rechange	
DVD POWER	DVD Power		Power
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
PROG / DIRECT	Prog/Direct	PROGRAM TV/ RADIO	TV/Radio /
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CALL	Call	GOTO TEXT	Text / Goto
0	0	HDMI - SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random

Original		Rechange	
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A-B REPEAT	A-B Repeat	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TOP MENU /PBC	Top Menu/PBC	TOP MENU D.MENU	D.Menu / Top
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
ANGLE	Angle	ANGLE INFO	Info / Angle
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
DISPLAY	Display	MEDIA DISPLAY	Display / Media
STOP	Stop	HOLD	Stop / Hold
STILL/PAUSE	Still/Pause	STEP - FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow

Original	Rechange	Original	Rechange
SLOW/SE << Slow/Search	TUNE- << / Tune-		
/SEARCH >> Slow/Search	TUNE+ >> / Tune+		
SKI I << Skip	PRESET- I << / Preset-		
SKIP >>I Skip	PRESET+ >>I / Preset+		
SETUP Setup	OPT-TOOLS SETUP Setup / OPT /		
NTSC/PAL NTSC/PAL	FORMAT PICTURE Picture / Format		
ZOOM Zoom	SIZE ZOOM Zoom / Size		
SLIDE SHOW Slide Show	LIST SMART Smart / List		