| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| MUTE | Mute | MUTE | Mute |
| MODE | Mode | APP MEDIA | Media |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| +/-- | - / - - | SHIFT + -/-- GUIDE | Shift + Guide |
| BACK | Back | RETURN BACK | Back |
| NICAM/A2 | Nicam/A2 | SOUND DUAL | Dual |

| Original | | Rechange | |
|---|---|---|---|
| TXT/MIX | TXT/MIX | REPEAT TEXT | Text |
| TXT/MIX | Play | PLAY MODE | Play |
| TXT/MIX | Pause | | Pause |
| CANCEL | Stop | | Stop |
| REC | Rec | REC MODE | Rec |
| INDEX | >>/Index | | >> |
| HOLD | <<</Hold | | << |
| SIZE | I << | | I << |
| REVEAL | >>I | | >>I |
| CANCEL | Cancel | CLEAR EXIT | Exit |
| MENU | Menu | TOP MENU MENU | Menu |
| DTV/RADIO | DTV/Radio | SEARCH TV/R | TV/R |
| VOL+ | Vol + | + VOL | Vol + |
| VOL- | Vol - | VOL - | Vol - |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Left | Left | FAV- | SHIFT + CH − Shift + Ch - |
| Enter | OK Ok | | |
| CH+ | + CH Ch + | | |
| CH- | CH − Ch - | | |
| FAV | FAV PRE-CH Pre Ch | | |
| EPG | -/-- GUIDE Guide | | |
| INFO | DISPLAY INFO Info | | |
| LIST | DISC NAV LIST List | | |
| RED | A Red | | |
| GREEN | B Green | | |
| YELLOW | C Yellow | | |
| BLUE | D Blue | | |
| SIZE | PICTURE FORMAT Format | | |
| REVEAL | ECO 3D 3D | | |
| SUBTITLE | AD SUBT Subt | | |
| SUBPAGE | TIMER AV AV | | |
| FAV+ | SHIFT + + CH Shift + Ch + | | |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | Vol + | Vol + |
| Mute | Mute | Vol - | Vol - |
| [ I ] / Menu | Menu | CH+ | Ch + |
| Exit | Exit | CH- | Ch - |
| Source | AV | Up | Up |
| 1 | 1 | Down | Down |
| 2 | 2 | Right | Right |
| 3 | 3 | Left | Left |
| 4 | 4 | OK | Ok |
| 5 | 5 | Recall | Back |
| 6 | 6 | Info | Info |
| 7 | 7 | EPG | Guide |
| 8 | 8 | Freeze | Options |
| 9 | 9 | Red | Red |
| 0 | 0 | Green | Green |
| Subtitle | Subt | Yellow | Yellow |
| Text | Text | Blue | Blue |

| Original | Rechange | | Original | Rechange |
|---|---|---|---|---|
| Audi o | SOUND DUAL | Dual | | |
| I <<</ [ ≡+] | | I << | | |
| >>I / [ ≡ . ] | | >>I | | |
| [ ≡i ] | HOME SMART | Smart | | |
| Pl ay | PLAY MODE ▶ | Pl ay | | |
| Pause | | Pause | | |
| St op | | St op | | |
| REP/ Rec | REC MODE | Rec | | |
| <</ [ ≡o] | | << | | |
| >>/ [ ≡?] | | >> | | |
| FAV | FAV PRE-CH | Pr e Ch | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |