# Mandis shop

Grandin GOLD001

| Original | | Rechange | |
|---|---|---|---|
| MARCHE | Marche | | Power |
| EJECT | Eject | SURROUND | Eject / Surround |
| | Up | | Up |
| EFF./CLEAR | EFF./Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Left | | Left |
| | Right | | Right |
| OK HORLOGE COMPT | OK/Horloge | OK | OK |
| | Down | | Down |
| i | i | ANGLE INFO | Info / Angle |
| PAUSE/ | Pause | STEP-FREEZE | Pause / Step / Freeze |
| AV | >>/AV | TUNE+ | >> / Tune+ |
| RET | <<RET | TUNE- | << / Tune- |
| LECT | Play/Lect | SLOW | Play / Slow |
| ENR/DEP | ENR/DEP | REC MODE | Rec / Rec Mode |
| STOP | Stop | HOLD | Stop / Hold |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |

| Original | | Rechange | |
|---|---|---|---|
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| TV/VIDEO | TV / Video | PROGRAM TV/RADIO | TV/Radio / |
| TV/VIDEO | TV / Video | SHIFT + VIDEO 4 | Shift + 4 |
| TV/VIDEO | TV / Video | SHIFT + TV 1 | Shift + 1 |
| 0 | 0 | HDMI-SAT 0 | 0 |
| ZAPPUB | Zappub | LIST SMART | Smart / List |
| LP | LP | OPT-TOOLS SETUP | Setup / OPT / |
| AV | AV | RDS AV INPUT | AV / Input / RDS |
| VERROUILLAGE | Verrouillage | MEDIA DISPLAY | Display / Media |
| SMART STOP | Smart Stop | SHIFT + HOLD | Shift + Stop / |
| SMART REPEAT | Smart Repeat | APP REPEAT | Green / APP / Repeat |

https://remotecontrols.fr/1069-881-telecommande-de-remplacement-pour-Grandin-GOLD001.html