Original		Rechange	
ON	Power On		Power
OFF	Power Off	SHIFT +	Shift + Power
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TITLE	Title	TITLE SOUND	Sound / Title
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
PLAYLIST	Playlist	LIST SMART	Smart / List
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
7	7	AUX-HDD 7	7

Original		Rechange	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
0	0	HDMI-SAT 0	0
INFO	Info	ANGLE INFO	Info / Angle
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
D.MENU	D. Menu	TOP MENU D.MENU	D. Menu / Top
STATUS	Status	MEDIA DISPLAY	Display / Media
PREVIOUS	I<<	PRESET-	I<< / Preset-
STOP	Stop	HOLD	Stop / Hold
NEXT/STEP	>>I	PRESET+	>>I / Preset+
SEARCH/SLOW	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
SEARCH/SLOW	>>	TUNE+	>> / Tune+
ANGLE	Angle	SHIFT + ANGLE INFO	Shift + Info / Angle
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
ZOOM	Zoom	SIZE ZOOM	Zoom / Size

Original		Rechange	
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
V.OFF	V. Off	RDS AV INPUT	AV / Input / RDS
DIMMER	Dimmer	DIMMER MUTE	Mute / Dimmer
P/I	P/I	FORMAT PICTURE	Picture / Format

Original	Rechange