Mandis shop

Haier HTR-A18EN

Original		Rechange	
	Power		Power
SOURCE	Source	TIMER AV	AV
P.MODE	P. Mode	PICTURE FORMAT	Format
S.MODE	S. Mode	SEARCH TV/R	TV/R
	Home	HOME SMART	Smart
1	1	1	1
2 abc	2	2	2
3 def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6 mno	6	6	6
7 pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0	0	0	0
Q.VIEW	Q. View	SETTINGS OPT	Options
SLEEP	Sleep	PROG SLEEP	Sleep

Original		Rechange	
	Mute	MUTE	Mute
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL –	Vol -
P	P+	+ CH	Ch +
P	P-	CH –	Ch -
AUDIO I/II	I/II / Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
You Tube	You Tube	APP MEDIA	Media
INFO/	Info	DISPLAY INFO	Info
FAV/	FAV	FAV PRE-CH	Pre Ch
SCREEN	Screen	ECO 3D	3D
CH.LIST/	CH List	DISC NAV LIST	List
MENU/	Menu	TOP MENU MENU	Menu
GUIDE/	Guide	- / -- GUIDE	Guide
	Up		Up
	Down		Down
	Right		Right

Original		Rechange		Original	Rechange
	Left		Left		
OK	OK	OK	Ok		
BACK/	Back	RETURN BACK	Back		
EXIT/	Exit	CLEAR EXIT	Exit		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
	Text	REPEAT TEXT	Text		
	<<	<<	<<		
	>>	>>	>>		
	I <<	I <<	I <<		
	>>I	>>I	>>I		
	Play	PLAY MODE	Play		
	Pause	II	Pause		
	Stop		Stop		
	Rec	REC MODE	Rec		