Original		Rechange	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
POWER	Power		Power
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7
10	10	HDMI-SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
FM MODE /MUTING	FM	DIMMER MUTE	Mute / Dimmer
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
PLAY MODE	Play Mode	LIST SMART	Smart / List

Original		Rechange	
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
CD	CD	SHIFT + CD-STB 3	Shift + 3
CD1	CD 1	TOP MENU D.MENU	D.Menu / Top
CD2	CD 2	OPT-TOOLS SETUP	Setup / OPT /
CD3	CD 3	GOTO TEXT	Text / Goto
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
S.A.BASS	SA Bass	EQ SUBTITLE	Subtitle / EQ
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
TREBLE	Treble	SURROUND	Eject / Surround
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SET	Set	OK	OK
TAPE DIRECTION	Tape Direction	HOME MENU	Menu / Home
	Play / Up	SLOW	Play / Slow
	Play / Up		Up
	Left		Left
VOLUME	Vol +	VOL +	Vol +
	Right		Right

Original	Rechange	Original	Rechange
Vol -	Vol -		
Stop / Down	Stop / Hold		
Stop / Down	Down		
Fade Muting	Sound / Title		

Original		Rechange	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
POWER	Power		Power
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7
10	10	HDMI-SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
FM MODE /MUTING	FM	DIMMER MUTE	Mute / Dimmer
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
PLAY MODE	Play Mode	LIST SMART	Smart / List

Original		Rechange	
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
CD	CD	SHIFT + CD-STB 3	Shift + 3
CD1	CD 1	TOP MENU D.MENU	D.Menu / Top
CD2	CD 2	OPT-TOOLS SETUP	Setup / OPT /
CD3	CD 3	GOTO TEXT	Text / Goto
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
S.A.BASS	SA Bass	EQ SUBTITLE	Subtitle / EQ
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
TREBLE	Treble	SURROUND ⏏	Eject / Surround
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SET	Set	OK	OK
TAPE DIRECTION	Tape Direction	HOME MENU	Menu / Home
▶	Play / Up	SLOW ▶	Play / Slow
▶	Play / Up	▲	Up
⏮	I<<| << / Left	TUNE- ◀◀	<< / Tune-
⏮	I<<| << / Left	◀	Left
⏮	I<<| << / Left	PRESET- ⏮	I<< / Preset-

Original		Rechange	
VOLUME	Vol +	VOL	Vol +
	>>I / >> / Right		Right
	>>I / >> / Right	PRESET+	>>I / Preset +
	>>I / >> / Right	TUNE+	>> / Tune+
VOLUME	Vol -	VOL	Vol -
	Stop / Down	HOLD	Stop / Hold
	Stop / Down		Down
FADE MUTING	Fade Muting	TITLE SOUND	Sound / Title

Original	Rechange

Original		Rechange	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
POWER	Power		Power
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7
10	10	HDMI-SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
FM MODE /MUTING	FM Mode/Mute	DIMMER MUTE	Mute / Dimmer
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
PLAY MODE	Play Mode	LIST SMART	Smart / List

Original		Rechange	
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
CD	CD	SHIFT + CD-STB 3	Shift + 3
CD1	Disc 1	TOP MENU D.MENU	D.Menu / Top
CD2	Disc 2	OPT-TOOLS SETUP	Setup / OPT /
CD3	Disc 3	GOTO TEXT	Text / Goto
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
S.A.BASS	SA Bass	EQ SUBTITLE	Subtitle / EQ
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
TREBLE	Treble	SURROUND	Eject / Surround
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SET	Set	OK	OK
TAPE DIRECTION	Tape Direction	HOME MENU	Menu / Home
	Play	SLOW	Play / Slow
	I<<<< / Left	TUNE-	<< / Tune-
	I<<<< / Left		Left
	I<<<< / Left	PRESET-	I<< / Preset-
VOLUME	Vol +	VOL +	Vol +

Original	Rechange	Original	Rechange
>>I / >> / Right	TUNE+ >> / Tune+		
>>I / >> / Right	Right		
>>I / >> / Right	PRESET+ >>I / Preset+		
VOLUME Vol -	VOL Vol -		
REC PAUSE Rec Pause	REC MODE Rec / Rec Mode		
REC PAUSE Rec Pause	STEP-FREEZE Pause / Step / Freeze		
Stop	HOLD Stop / Hold		
FADE MUTING Fade Muting	TITLE SOUND Sound / Title		