| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | Open/Close | | Eject |
| | Radio & Input | | AV |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | Clear | | Exit |
| | Repeat | | Text |
| | I << | | I << |
| | << | | << |

| Original | | Rechange | |
|---|---|---|---|
| | >> | | >> |
| | >>I | | >>I |
| | Stop | | Stop |
| | Play | | Play |
| | Pause | | Pause |
| | Speaker Level | | Dual |
| | Sound Effect | | Subt |
| | Optical | | Options |
| | Vol + | | Vol + |
| | Vol - | | Vol - |
| | Mute | | Mute |
| | Home | | Smart |
| | 3D Sound | | 3D |
| | Info/Display | | Info |
| | Back | | Back |
| | Title/Pop Up | | Media |
| | Disc Menu | | D. Menu |

| Original | Rechange |
|---|---|
| Up/ Preset + | Up |
| Down/ Preset - | Down |
| Right / Tuning+ | Right |
| Left / Tuning- | Left |
| Enter | Ok |
| Red/ RDS | Red |
| Green/ PTY | Green |
| Yellow/ PTY Search | Yellow |
| Blue/ Mono/ Stereo | Blue |
| Marker | Format |
| Search | TV/ R |
| Sleep | Sleep |
| Music ID | List |
| Rec | Rec |
| Power Tv | Shift + Power |
| AV Input TV | Shift + AV |
| Vol + TV | Shift + Vol + |

| Original | Rechange |
|---|---|
| Vol - TV | Shift + Vol - |
| PR/ CH+ Tv | Ch + |
| PR/ CH- Tv | Ch - |