Mandis shop

Original		Rechange	
POWER	Power	POWER	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
FM/AM	FM/AM	SHIFT + TUNER 6	Shift + 6
CD/DVD	CD/DVD	SHIFT + CD-STB 3	Shift + 3
CD/DVD	CD/DVD	SHIFT + DVD 2	Shift + 2
VIDEO 1	Video 1	SHIFT + TV 1	Shift + 1
VIDEO 2	Video 2	SHIFT + VIDEO 4	Shift + 4
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
PRESET-	Preset-	CH PAGE –	CH- / Page-
PRESET-	Preset-	SHIFT + PRESET- ⏮	Shift + I<< / Preset-
PRESET+	Preset+	+ CH PAGE	CH+ / Page+
PRESET+	Preset+	SHIFT + PRESET+ ⏭	Shift + >>I / Preset+
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Rechange	
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
VOLUME-	Volume-	VOL –	Vol -
VOLUME+	Volume+	+ VOL	Vol +
PLAY	Play	SLOW ▶	Play / Slow
PAUSE/STEP	Pause / Step	STEP-FREEZE ⏸	Pause / Step / Freeze
STOP	Stop	HOLD ■	Stop / Hold
I<< <<	I<< << / Skip-	PRESET- ⏮	I<< / Preset-
>> >>I	>> >>I / Skip+	PRESET+ ⏭	>>I / Preset+
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
TEST TONE	Test Tone	GOTO TEXT	Text / Goto
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title
BY PASS	By Pass	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Mandis shop

Original	Rechange	Original	Rechange
Up	Up	Marker	Fav / Marker / PC
Level	Picture / Format	Title	Shift + Sound / Title
Delay	D. Menu / Top	Clear	Exit / Cancel / Clear
Left	Left	Search	Red / Netflix / Search
Enter	OK	>> Fwd /	>> / Tune+
Right	Right		
Display	Display / Media		
Return	Back / Return		
Down	Down		
Set-Up	Setup / OPT /		
Menu	Menu / Home		
S-Title	Subtitle / EQ		
Angle	Info / Angle		
Audio	Audio / Lang I/II		
Rev << / Slow/Scaner-	<< / Tune-		
Repeat A-B	Shift + Yellow / YouTube /		
Zoom	Zoom / Size		