Original		Rechange	
	Power		Power
	Mute	MUTE	Mute
MOSAICO	Mosaico	DISC NAV LIST	List
DVR GRAVAÇÕES	DVR / Gravaçoes	APP MEDIA	Media
VOD VIDEOCLUBE	VOD / Videoclube	HOME SMART	Smart
PESQUISA	Pesquisa	SHIFT + SEARCH TV/R	Shift + TV/R
EXIT	Exit	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
	i	DISPLAY INFO	Info
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
	P +	CH +	Ch +

Original		Rechange	
	P -	CH −	Ch -
STOP	Stop		Stop
	<<		<<
	Pause		Pause
	Play	PLAY MODE	Play
	>>		>>
REC	Rec	REC MODE	Rec
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	I<<		I<<
BACK	Back	RETURN BACK	Back
RÁDIO TXT	Radio / TXT	SEARCH TV/R	TV/R
RÁDIO TXT	Radio / TXT	REPEAT TEXT	Text
	>>I		>>I
1	1	1	1

Original		Rechange		Original		Rechange	
2	2	2	2				
3	3	3	3				
4	4	4	4				
5	5	5	5				
6	6	6	6				
7	7	7	7				
8	8	8	8				
9	9	9	9				
0	0	0	0				
GUIA PROGRAMAÇÃO	GUIA /	-/-- GUIDE	Guide				
* AV	* / AV	TIMER AV	AV				
#	# / -/--	SHIFT + -/-- GUIDE	Shift + Guide				