Mandis shop

Sanyo MXCE

Original		Rechange		Original		Rechange	
ON	On		Power	IMAGE SEL.	Image Sel	TOP MENU D.MENU	D. Menu / Top
STAND-BY	Standby	SHIFT +	Shift + Power	IMAGE ADJ.	Image Adj.	GOTO TEXT	Text / Goto
SHUTTER	Shutter	LIST SMART	Smart / List	INPUT 1	Input 1	OPT-TOOLS SETUP	Setup / OPT /
INPUT	Input	RDS AV INPUT	AV / Input / RDS	FREEZE 1	1/Freeze	TV 1	1
MENU	Menu	HOME MENU	Menu / Home	D.ZOOM 2	2/DZoom+-	DVD 2	2
	Up		Up	INPUT 2 3	3/Input 2	CD - STB 3	3
AUTO PC	Auto PC	MEDIA DISPLAY	Display / Media	LENS SHIFT 4	4/Lens Shift	VIDEO 4	4
VOL-	Left		Left	KEYSTONE 5	5/Keystone	TAPE 5	5
VOL-	Vol -	VOL −	Vol -	INPUT 3 6	6/Input 3	TUNER 6	6
SELECT	Select	OK	OK	ZOOM 7	7/Zoom+-	AUX - HDD 7	7
VOL+	Right		Right	FOCUS 8	8/Focus Left	USB 8	8
VOL+	Vol +	+ VOL	Vol +	INFO. 9	9/Info	BLUETOOTH 9	9
MUTE	Down		Down	ZOOM	Zoom-	PRESET-	I<< / Preset-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	FOCUS 0	0/Focus Right	HDMI - SAT 0	0
P-TIMER	P-Timer	PC FAV MARKER	Fav / Marker / PC	FILTER	Filter	LANG I/II AUDIO	Audio / Lang I/II
POINTER	Pointer	-/-- GUIDE EPG	Guide / EPG / -/--	PIP	PIP	SIZE ZOOM	Zoom / Size
SCREEN	Screen	FORMAT PICTURE	Picture / Format				

https://www.telecommande-de-remplacement.com/fr/1624-804-telecommande-de-remplacement-pour-Sanyo-MXCE-651386.htm