Original		Rechange	
	Power		Power
– LEVE	Level -	CH PAGE –	CH- / Page-
– LEVE	Level -	VOL –	Vol -
EVEL +	Level +	+ CH PAGE	CH+ / Page+
EVEL +	Level +	+ VOL	Vol +
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
≥10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
PROGRAM	Program	PROGRAM TV/ RADIO	TV/ Radio / Program

Original		Rechange	
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
RECALL	Recall	RETURN BACK	Back / Return
TIME MODE	Time Mode	TIMER SLEEP	Sleep / Timer
A-B REPEAT	A-B Repeat	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
AUTO CUE	Auto Cue	LIST SMART	Smart / List
TAPE LENGTH	Tape Length		Up
SIDE A/B	Side A-B		Left
TIME FADE	Time Fade		Right
PEAK SEARCH	Peak Search	NETFLIX SEARCH	Red / Netflix / Search
PEAK SEARCH	Peak Search		Down
◀◀ SEA	<< Search	TUNE- ◀◀	<< / Tune-
RCH ▶▶	Search >>	TUNE+ ▶▶	>> / Tune+
⏏ OPEN/CLOSE	Open/Close	SURROUND ⏏	Eject / Surround
|◀◀ SK	|<< Skip	PRESET- |◀◀	|<< / Preset-
KIP ▶▶|	Skip >>|	PRESET+ ▶▶|	>>| / Preset+

Original		Rechange		Original	Rechange
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		