Original	Rechange	Original	Rechange
Power	Power	Stop/ Open/ Clos	Stop
Red	Red	Stop/ Open/ Clos	Eject
Green	Green	>>	>>
Yellow	Yellow	<<	<<
Blue	Blue	>I	>>I
Pop Up Menu/ Disc Menu	D. Menu	I <	I <<
Top Menu	Menu	1	1
Home	Smart	2	2
OK	Ok	3	3
Up	Up	4	4
Down	Down	5	5
Right	Right	6	6
Left	Left	7	7
Back	Back	8	8
≡/ Options	Options	9	9
Play	Play	0	0
Pause	Pause	Subtitle	Subt

Original	Rechange	Original	Rechange
AUDIO Audi o	SOUND DUAL Dual		