Original	Rechange	Original	Rechange
Power	Power	Input 5	Shift + 5
Input 1	Shift + 1	[II]	Setup / OPT /
Input 2	Shift + 2	[<>]	Picture / Format
Input 3	Shift + 3	Back	Back / Return
Input 4	Shift + 4	Pr+	CH+ / Page+
1	1	Tv/DTV	TV/Radio /
2	2	Vol +	Vol +
3	3	Pr-	CH- / Page-
4	4	Mute	Mute / Dimmer
5	5	Vol -	Vol -
6	6	Source	AV / Input / RDS
7	7	Return	Shift + Back / Return
8	8	Up	Up
9	9	Home	Menu / Home
PC	Fav / Marker / PC	Left	Left
0	0	Enter	OK
[i+]	Info / Angle	Right	Right

Original		Rechange		Original	Rechange
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	Down		Down		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
	Red/Rec	NETFLIX SEARCH	Red / Netflix / Search		
	Green/Pause	APP REPEAT	Green / APP / Repeat		
	Yellow/Stop	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue/Play	Prime Video RANDOM	Blue / Prime Video / Random		
	[...]	EQ SUBTITLE	Subtitle / EQ		
	[≡?]	TUNE-	<< / Tune-		
	[≡i]	TUNE+	>> / Tune+		
	Text	GOTO TEXT	Text / Goto		
HDMI CONTROL	HDMI Control	LIST SMART	Smart / List		
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II		
	[>I <]	STEP-FREEZE	Pause / Step / Freeze		
	Size [<>]	SIZE ZOOM	Zoom / Size		

Original	Rechange	Original	Rechange
Power	Power	Vol +	Vol +
Input 1	SHIFT + TV 1 Shift + 1	Mute	DIMMER MUTE Mute / Dimmer
Input 2	SHIFT + DVD 2 Shift + 2	Vol -	VOL Vol -
Input 3	SHIFT + CD-STB 3 Shift + 3	SOURCE Source	RDS AV INPUT AV / Input / RDS
Input 4	SHIFT + VIDEO 4 Shift + 4	RETURN Return	RETURN BACK Back / Return
1	TV 1 1	Up	Up
2	DVD 2 2	HOME MENU Menu	HOME MENU Menu / Home
3	CD-STB 3 3	Left	Left
4	VIDEO 4 4	ENTER Enter	OK OK
5	TAPE 5 5	Right	Right
6	TUNER 6 6	Down	Down
7	AUX-HDD 7 7	EPG DVD Top	-/-- GUIDE EPG Guide / EPG / -/--
8	USB 8 8	EPG DVD Top	TOP MENU D.MENU D. Menu / Top
9	BLUETOOTH 9 9	Pause	STEP-FREEZE Pause / Step / Freeze
PC	PC FAV MARKER Fav / Marker / PC	Stop	HOLD Stop / Hold
0	HDMI-SAT 0 0	Play	SLOW Play / Slow
INPUT 5	SHIFT + TAPE 5 Shift + 5	I <<	PRESET- I << / Preset-

Original	Rechange	Original	Rechange
>>I	>>I / Preset+		
<<	<< / Tune-		
>>	>> / Tune+		
HDMI Control	Smart / List		

Original		Rechange	
Power		Power	
Input 1		SHIFT + TV 1	Shift + 1
Input 2		SHIFT + DVD 2	Shift + 2
Input 3		SHIFT + CD-STB 3	Shift + 3
Input 4		SHIFT + VIDEO 4	Shift + 4
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PC	PC	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI-SAT 0	0
[i+]		ANGLE INFO	Info / Angle

Original		Rechange	
INPUT 5	Input 5	SHIFT + TAPE 5	Shift + 5
P+	PR+	CH PAGE +	CH+ / Page+
Vol +	Vol +	VOL +	Vol +
P-	PR-	CH PAGE -	CH- / Page-
Mute	Mute	DIMMER MUTE	Mute / Dimmer
Vol -	Vol -	VOL -	Vol -
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
Up	Up	Up	Up
HOME MENU	Menu	HOME MENU	Menu / Home
HOME MENU	DVD Top Menu	TOP MENU D.MENU	D.Menu / Top
Left	Left	Left	Left
ENTER	Enter	OK	OK
Right	Right	Right	Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Down	Down	Down	Down
EPG	DVD Top Menu	-/-- GUIDE EPG	Guide / EPG / -/--
HDMI CONTROL	HDMI Control	LIST SMART	Smart / List

Original		Rechange	
Power		Power	
Input 1		SHIFT + TV 1	Shift + 1
Input 2		SHIFT + DVD 2	Shift + 2
Input 3		SHIFT + CD-STB 3	Shift + 3
Input 4		SHIFT + VIDEO 4	Shift + 4
1		TV 1	
2		DVD 2	
3		CD-STB 3	
4		VIDEO 4	
5		TAPE 5	
6		TUNER 6	
7		AUX-HDD 7	
8		USB 8	
9		BLUETOOTH 9	
PC		PC FAV MARKER	Fav / Marker / PC
0		HDMI-SAT 0	
INPUT 5		SHIFT + TAPE 5	Shift + 5

Original		Rechange	
PR+		CH PAGE +	CH+ / Page+
Vol +		VOL +	Vol +
PR-		CH PAGE -	CH- / Page-
Mute		DIMMER MUTE	Mute / Dimmer
Vol -		VOL -	Vol -
Source		RDS AV INPUT	AV / Input / RDS
Rec		REC MODE	Rec / Rec Mode
Pause		STEP-FREEZE	Pause / Step / Freeze
Stop		HOLD	Stop / Hold
Play		SLOW	Play / Slow
<<		TUNE-	<< / Tune-
>>		TUNE+	>> / Tune+
HDMI CONTROL	HDMI Control	LIST SMART	Smart / List