Mandis shop

Pioneer PWW1175

Original		Rechange	
	Power		Power
DIMMER	Dimmer	DIMMER MUTE	Mute / Dimmer
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
PURE AUDIO	Pure Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	>>I	PRESET+	>>I / Preset+
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Rechange	
6	6	TUNER 6	6
ENTER	Enter	OK	OK
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
TIME	Time	TIMER SLEEP	Sleep / Timer
SACD SETUP	SACD Setup	OPT-TOOLS SETUP	Setup / OPT /
LEGATO LINK	Legato Lynk	LIST SMART	Smart / List

https://remotes.fr/Pioneer/1585-264-telecommande-de-replacement-pour-Pioneer-PWW1175.htm