Mandis shop

CU- XR032

Original		Rechange	
VOL	Vol -	VOL –	Vol -
VOL ▲	Vol +	+ VOL	Vol +
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
POWER	Power		Power
KARAOKE	Karaoke	LIST SMART	Smart / List
SFC	SFC	FORMAT PICTURE	Picture / Format
P.BASS	P. Bass	TITLE SOUND	Sound / Title
DISPLAY	Display	MEDIA DISPLAY	Display / Media
AUX	AUX	AUX - HDD 7	7
1	Disc 1	TV 1	1
2	Disc 2	DVD 2	2
3	Disc 3	CD - STB 3	3
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
PGM	PGM	OPT-TOOLS SETUP	Setup / OPT /
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
I<< CD	I<< CD	PRESET- I<<	I<< / Preset-

Original		Rechange	
>>I CD	>>I CD	PRESET+ >>I	>>I / Preset+
■	Stop CD	HOLD ■	Stop / Hold
II/▶	Play CD	SLOW ▶	Play / Slow
II/▶	Pause CD	STEP-FREEZE II	Pause / Step / Freeze
◀◀	<< Tape I	TUNE- ◀◀	<< / Tune-
▶▶	>> Tape I	TUNE+ ▶▶	>> / Tune+
■	Stop Tape I	SHIFT + HOLD ■	Shift + Stop /
I ◀▶	<> Tape I	SHIFT + SLOW ▶	Shift + Play /
◀◀	<< Tape II	◀	Left
▶▶	>> Tape II	▶	Right
■	Stop Tape I	▼	Down
◀▶ II	<> Tape II	▲	Up
▼STATI	Station Down	CH PAGE –	CH- / Page-
TATION▲	Station Up	+ CH PAGE	CH+ / Page+
MONO	Mono	LANG I/II AUDIO	Audio / Lang I/II
BAND	Band	PROGRAM TV/ RADIO	TV/ Radio /

https://remotecontrols.fr/Pioneer/1678-870-telecommande-de-remplacement-pour-Pioneer-AD710-CU-XR032.htm