Original	Rechange	Original	Rechange
Power	Power	1	1
Red / Setup	Red / Netflix / Search	2	2
Red / Setup	Setup / OPT /	3	3
Green / APP	Green / APP / Repeat	4	4
Yellow / Vol	Yellow / YouTube / Repeat	5	5
Yellow / Vol	Vol -	6	6
Blue / Vol +	Blue / Prime Video / Random	7	7
Blue / Vol +	Vol +	8	8
Home / Menu	Menu / Home	9	9
Back	Back / Return	Mute	Mute / Dimmer
Up	Up	0	0
Left	Left	<X] / Exit	Exit / Cancel / Clear
OK	OK		
Right	Right		
[≡]	Text / Goto		
Down	Down		
Mouse	Smart / List		

https://remote-controls.ch/fr/GOLDEN-INTERSTAR-10103-9581-telecommande-de-replacement-pour-GOLDEN-INTERSTAR-G-150.html