Original		Rechange	
	Power		Power
	Mute	MUTE	Mute
	Open/Close	ZOOM	Eject
CD	CD	1	1
Bluetooth	Bluetooth	3	3
TV SoundConnect	Tv	6	6
USB	USB	2	2
USB REC	USB Rec	REC MODE	Rec
REC SPEED	Rec Speed	0	0
TUNER	Tuner	4	4
TUNING MODE	Tuning Mode	7	7
MO/ST	MO/ST	8	8
AUX	AUX	5	5
NON-STOP RELAY	Non-Stop Relay	9	9
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info
PRESET EQ	Preset EQ	TOP MENU MENU	Menu
USER EQ	User EQ	-/-- GUIDE	Guide

Original		Rechange	
MEMORY	Memory	HOME SMART	Smart
TUNING	I<<<Tuning		I<<
TUNING	>>I/Tuning		>>I
	<<		<<
	>>		>>
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
REPEAT	Repeat	REPEAT TEXT	Text
FOOTBALL	Football	RETURN BACK	Back
GIGA	Giga	APP MEDIA	Media
AUTO CHANGE	Auto Change	DISPLAY INFO	Info
VOL +	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
SEARCH	Search	SEARCH TV/R	TV/R
MY LIST	My List	DISC NAV LIST	List
	Up		Up

Original		Rechange	
	Down		Down
EFFECT +	Folder +/ Effect		Right
EFFECT –	Folder - / Effect		Left
	Enter	OK	Ok
TIMER ON/OFF	Timer On/ Off	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
TIMER SET	Timer Set	E-MANUAL D.MENU	D. Menu
DELETE	Delete	CLEAR EXIT	Exit
BEAT WAVING	Beat Waving	A	Red
MY KARAOKE	My Karaoke	B	Green
MIC VOL +	Mic Vol +	+ CH	Ch +
MIC –	Mic Vol -	CH –	Ch -

Original	Rechange