Mandis shop

Sony RM-SC50

Original		Rechange	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
I / ⏻	Power	⏻	Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
SELECT	Clock Timer	TOP MENU D.MENU	D. Menu / Top
SET	Clock Timer Set	HOME MENU	Menu / Home
TUNER MEMORY	Tuner Memory	◀	Left
PLAY MODE/ TUNING MODE	Play Mode/ Tuning Mode	▶	Right
REPEAT/ FM MODE	Repeat / FM	APP REPEAT	Green / APP / Repeat
REPEAT/ FM MODE	Repeat / FM	▼	Down
TAPE	Tape	TAPE 5	5
CD	CD	CD - STB 3	3
TUNER BAND	Band/ Tuner	▲	Up
TUNER BAND	Band/ Tuner	TUNER 6	6
FUNCTION	Function	LIST SMART	Smart / List
− ⏮	I <<I / -	PRESET- ⏮	I << / Preset -
+ ⏭	>>I / +	PRESET+ ⏭	>>I / Preset +
◀◀	<<	TUNE- ◀◀	<< / Tune-

Original		Rechange	
▶▶	>>	TUNE+ ▶▶	>> / Tune+
▶	Play	SLOW ▶	Play / Slow
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOLUME +	Vol +	+ VOL	Vol +
ENTER	Enter	OK	OK
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
VOLUME −	Vol -	VOL −	Vol -
DISC SKIP	Disc Skip	SURROUND ⏏	Eject / Surround
🗀 −	Folder -	CH PAGE −	CH- / Page-
🗀 +	Folder +	+ CH PAGE	CH+ / Page+

https://remotecontrols.fr/Sony/1055-603-telecommande-remplacement-pour-Sony-RM-SC50-A1083B.htm