Mandis shop

Sony RMT-463

Original		Rechange		Original	Rechange
	Power		Power		
COUNTER RESET	Counter Reset	APP MEDIA	Media		
GO TO ZERO	Goto Zero	HOME SMART	Smart		
	Rec	REC MODE	Rec		
PAUSE	Pause		Pause		
X2	X2	PICTURE FORMAT	Format		
FRAME	I I > Frame	PROG SLEEP	Sleep		
X1/10	X1/10	TIMER AV	AV		
X1/5	X1/5	ECO 3D	3D		
PLAY	Play	PLAY MODE	Play		
	Search >>		>>		
	<< Search		<<		
FF	FF >>		>>I		
REW	<< Rew		I <<		
STOP	Stop		Stop		

https://remotecontrols.fr/Sony/1647382/telecommande-remplacement-pour-Sony-RMT-463-145501.htm