Original		Rechange	
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
- -	- -	-/-- GUIDE EPG	Guide / EPG / -/--
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
P<P	P<P	PC FAV MARKER	Fav / Marker / PC
MENU	Menu	HOME MENU	Menu / Home
P+	Up / P+		Up
P+	Up / P+	CH PAGE	CH+ / Page+
	[i]	ANGLE INFO	Info / Angle

Original		Rechange	
◄-VOL	Left / Vol -		Left
◄-VOL	Left / Vol -	VOL −	Vol -
OK	OK	OK	OK
VOL+►	Right / Vol +		Right
VOL+►	Right / Vol +	+ VOL	Vol +
I/II	I/II	LANG I/II AUDIO	Audio / Lang I/II
P-	Down / P-	CH PAGE −	CH- / Page-
P-	Down / P-		Down
PP	PP	RETURN BACK	Back / Return
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /
TV	TV	SHIFT + TV 1	Shift + 1
AV	AV	RDS AV INPUT	AV / Input / RDS
	Mute	DIMMER MUTE	Mute / Dimmer
SOUND	Red / Sound	NETFLIX SEARCH	Red / Netflix / Search
SOUND	Red / Sound	TITLE SOUND	Sound / Title
PICTURE	Green / Picture	FORMAT PICTURE	Picture / Format
PICTURE	Green / Picture	APP REPEAT	Green / APP / Repeat

Original	Rechange	Original	Rechange
FEATURE Yellow / Feature	YouTube REPEAT A-B Yellow / YouTube / Repeat		
INSTALL Blue / Install	Prime Video RANDOM Blue / Prime Video / Random		
[≡]	GOTO TEXT Text / Goto		
[≡◷]	SLOW ▶ Play / Slow		
[≡▯]	HOLD ■ Stop / Hold		
[≡X] / [▬]	CLEAR EXIT CANCEL Exit / Cancel / Clear		
[/ ≡] [■]	SHIFT + GOTO TEXT Shift + Text /		
[≡↕] / [▯]	SIZE ZOOM Zoom / Size		
[≡?] / PC	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC		
[≡]	STEP-FREEZE ⏸ Pause / Step / Freeze		