Original		Rechange	
	Power		Power
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /
0	0	HDMI - SAT 0	0
	Recall	SHIFT + RETURN BACK	Shift + Back / Return
V+	Vol +	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P+	P+	+ CH PAGE	CH+ / Page+

Original		Rechange	
V−	Vol -	VOL −	Vol -
@	@	MEDIA DISPLAY	Display / Media
P−	P-	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
▲	Up	▲	Up
Q. MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
BACK	Back	RETURN BACK	Back / Return
▼	Down	▼	Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	World	ANGLE INFO	Info / Angle
	Music/Movie/Phot	TITLE SOUND	Sound / Title
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
HELP	Help	OPT-TOOLS SETUP	Setup / OPT /
★/	*/Q	FORMAT PICTURE	Picture / Format

Original		Rechange		Original	Rechange
	[≡]	GOTO TEXT	Text / Goto		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
LANG.	Lang	LANG I/II AUDIO	Audio / Lang I/II		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
	[-O-]	SIZE ZOOM	Zoom / Size		
	<<	TUNE-	<< / Tune-		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	>>	TUNE+	>> / Tune+		
	Rec	REC MODE	Rec / Rec Mode		
	Play	SLOW	Play / Slow		
	Stop	HOLD	Stop / Hold		