Originale	Sostituto
Power	Power
Input TV	TV/Radio /
Input Av	AV / Input / RDS
Guide	Guide / EPG / -/--
Up	Up
Exit	Exit / Cancel / Clear
Left	Left
OK	OK
Right	Right
Menu	Menu / Home
Down	Down
Return	Back / Return
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
[+]/Aspect	Picture / Format

Originale	Sostituto
Link Vieta	Smart / List
Option	Setup / OPT /
Direct Tv Rec	Shift + Rec / Rec Mode
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
i	Info / Angle
0/VCR	0
0/VCR	Shift + 4
Mute	Mute / Dimmer
CH+	CH+ / Page+

Originale	Sostituto
Vol +	Vol +
CH-	CH- / Page-
Vol -	Vol -
[≡] / Text	Text / Goto
[≡♦] / STTL	Subtitle / EQ
[≡i] / Index	Display / Media
[≡+] / Hold	Shift + Stop /
Power DVD	Shift + Power
Rec DVD	Rec / Rec Mode
Programme Down	Shift + CH- /
Programme Up	Shift + CH+ /
<<| << DVD	<< / Tune-
<<| << DVD	<< / Preset-
>>| >> DVD	>> / Preset+
>>| >> DVD	>> / Tune+
Stop DVD	Stop / Hold
Pause/Step DVD	Pause / Step / Freeze

Originale	Sostituto
Play DVD	Play / Slow

Originale	Sostituto
Power DVD	Power
Rec DVD	Rec / Rec Mode
Programme Down	CH- / Page-
Programme Up	CH+ / Page+
I << DVD	I << / Preset-
I << DVD	<< / Tune-
>>I DVD	>>I / Preset+
>>I DVD	>> / Tune+
Stop DVD	Stop / Hold
Pause/Step DVD	Pause / Step / Freeze
Play DVD	Play / Slow

Originale	Sostituto

Originale	Sostituto
Power VCR	Power
Rec VCR	Rec / Rec Mode
Programme Down	CH- / Page-
Programme Up	CH+ / Page+
<<| << VCR	<< / Preset-
<<| << VCR	<< / Tune-
>>| >> VCR	>> / Tune+
>>| >> VCR	>> / Preset+
Stop VCR	Stop / Hold
Pause/Step VCR	Pause / Step / Freeze
Play VCR	Play / Slow

Originale	Sostituto