Originale	Sostituto	Originale	Sostituto
DVD	TV/ R	Right	Right
Power	Power	Down	Down
1	1	Left	Left
2	2	Enter	Ok
3	3	Display	Info
4	4	Return	Back
5	5	I << / <<	<<
6	6	I <<	I <<
7	7	>> / >>I	>>
8	8	>>I	>>I
9	9	Stop	Stop
0	0	Play	Play
-/--/+10	Guide	Delay	Options
Top Menu	Shift + Menu	Level	Media
Top Menu	D. Menu	-	Ch -
Menu	Menu	+	Ch +
Up	Up	Subwoofer	Subt

Originale		Sostituto		Originale		Sostituto	
SOUND MODE	Sound Mode	SOUND DUAL	Dual				
SFC	SFC	TIMER AV	AV				
TEST	Test	REPEAT TEXT	Text				
MUTING	Muting	MUTE	Mute				
VOL −	Vol -	VOL −	Vol -				
+ VOL	Vol +	+ VOL	Vol +				

Originale	Sostituto
CD	TV/R
Power CD	Power
1 CD	1
2 CD	2
3 CD	3
4 CD	4
5 CD	5
6 CD	6
7 CD	7
8 CD	8
9 CD	9
0 CD	0
+10/-/-- CD	Guide
Direct Tuning/Disc CD	Pre Ch
Play CD	Play
Stop CD	Stop
I<</<< CD	<<

Originale	Sostituto
>>/>>I CD	>>
TV	Shift + TV/R
Power TV	Shift + Power
1 TV	Shift + 1
2 TV	Shift + 2
3 TV	Shift + 3
4 TV	Shift + 4
5 TV	Shift + 5
6 TV	Shift + 6
7 TV	Shift + 7
8 TV	Shift + 8
9 TV	Shift + 9
0 TV	Shift + 0
+10/-/-- TV	Shift + Guide
Vol + TV	Vol +
Vol - TV	Vol -
TV/AV	AV

Originale	Sostituto
VCR	TV/ R
Power VCR	Power
1 VCR- Tape	1
2 VCR- Tape	2
3 VCR- Tape	3
4 VCR- Tape	4
5 VCR- Tape	5
6 VCR- Tape	6
7 VCR- Tape	7
8 VCR- Tape	8
9 VCR- Tape	9
0 VCR- Tape	0
+10/ - / - - VCR	Gui de
Pl ay VCR	Pl ay
St op VCR	St op
I <</ << VCR	<<
I << VCR	I <<

Originale	Sostituto
>>/ >>I VCR	>>
>>I VCR	>>I
Tape	Shi f t + TV/ R
Power Tape	Shi f t + Power
Pl ay Tape	Shi f t + Pl ay
St op Tape	Shi f t + St op
I <</ << Tape	Shi f t + <<
I << Tape	Shi f t + I <<
>>/ >>I Tape	Shi f t + >>
>>I Tape	Shi f t + >>I

Originale	Sostituto
Tuner - Band	TV/ R
Power Tuner - Band	Power
1 Tuner - Band	1
2 Tuner - Band	2
3 Tuner - Band	3
4 Tuner - Band	4
5 Tuner - Band	5
6 Tuner - Band	6
7 Tuner - Band	7
8 Tuner - Band	8
9 Tuner - Band	9
0 Tuner - Band	0
+10/ - / - -	Gui de
Di rect Tuni ng/ Di sc	Pre Ch
Pl ay	Pl ay
St op	St op
I <</ <<	<<

Originale	Sostituto
I << Tuner - Band	I <<
>>/ >>I	>>
>>I Tuner - Band	>>I
MD	Shi ft + TV/ R
Power MD	Shi ft + Power
1 MD	Shi ft + 1
2 MD	Shi ft + 2
3 MD	Shi ft + 3
4 MD	Shi ft + 4
5 MD	Shi ft + 5
6 MD	Shi ft + 6
7 MD	Shi ft + 7
8 MD	Shi ft + 8
9 MD	Shi ft + 9
0 MD	Shi ft + 0
+10/ - / - - MD	Shi ft + Gui de
Pl ay MD	Shi ft + Pl ay

Tuner - Band

Originale	Sostituto	Originale	Sostituto
Stop MD	SHIFT + Shift + Stop		
I <</ << MD	SHIFT + Shift + <<		
I << MD	SHIFT + Shift + I <<		
>>/ >>I MD	SHIFT + Shift + >>		
>>I MD	SHIFT + Shift + >>I		