Originale		Sostituto	
	Power Tv		Power
	Vol + Tv		Vol +
	Vol - Tv		Vol -
	Func Tv		D. Menu
	CH+ Tv		Ch +
	CH- Tv		Ch -
	Menu Tv		Menu
	Enter Tv		Ok
	Up/FQ+ Tv		Up
	Down/FQ- Tv		Down
	Right/ST+ Tv		Right
	Left/ST- Tv		Left
	Stop/Class Tv		Stop
	Pause/MPX Tv		Pause
	Play/Band Tv		Play
	1 Tv		1
	2 Tv		2

Originale		Sostituto	
	3 Tv		3
	4 Tv		4
	5 Tv		5
	6 Tv		6
	7 Tv		7
	8 Tv		8
	9 Tv		9
	0 Tv		0
	+10 Tv		Guide
	Disc		Pre Ch
	Tuner		Blue
	Power Tuner		Shift + Power
	Class Tuner		Text
	MPX Tuner		AV
	Band Tuner		Format
	D.Access Tuner		3D
	Display Tuner		Info

Originale	Sostituto	Originale	Sostituto
RF ATT	Back		
Up Tuner	Shift + Up		
Down Tuner	Shift + Down		
Right Tuner	Shift + Right		
Left Tuner	Shift + Left		
1 Tuner	Shift + 1		
2 Tuner	Shift + 2		
3 Tuner	Shift + 3		
4 Tuner	Shift + 4		
5 Tuner	Shift + 5		
6 Tuner	Shift + 6		
7 Tuner	Shift + 7		
8 Tuner	Shift + 8		
9 Tuner	Shift + 9		
0 Tuner	Shift + 0		

Originale	Sostituto
Power	Power
Muting	Mute
Master Vol +	Vol +
Master Vol -	Vol -
Function	D. Menu
Loudness	Dual
Remote Setup	Smart
FL Dimmer	Media
Enter	Ok
Up/ FQ+	Up
Down/ FQ-	Down
Left / ST-	Left
Right / ST+	Right
1/ [ ) ( ]	1
2/ DSP Mode	2
3/ Midnight	3
4/ 5. 1CH	4

Originale	Sostituto
5/ Channel Select	5
6/ Test Tone	6
7/ ATT	7
8/ Signal Selec	8
9/ Channel Level -	9
0/ Channel Level +	0
+10/ Effect -	Guide
Disc/ Effect +	Pre Ch
DVD/ LD	Blue
Power DVD/ LD	Shift + Power
Stop/ Class	Stop
Pause/ MPX	Pause
Play/ Band DVD/ LD	Play
<</ D. Access	<<
>> DVD/ LD	>>
I <</ Display/ Channel - DVD/ LD	I <<
>>I / Display/ Channel + DVD/ LD	>>I

Originale	Sostituto	Originale	Sostituto
Up/ FQ+ DVD/ LD	SHIFT + Shift + Up	Top Menu	SHIFT + Shift + Menu
Down/ FQ-	SHIFT + Shift + Down		
Right / ST+	SHIFT + Shift + Right		
Left / ST- DVD/ LD	SHIFT + Shift + Left		
Enter DVD/ LD	SHIFT + Shift + Ok		
1 DVD/ LD	SHIFT + Shift + 1		
2 DVD/ LD	SHIFT + Shift + 2		
3 DVD/ LD	SHIFT + Shift + 3		
4 DVD/ LD	SHIFT + Shift + 4		
5 DVD/ LD	SHIFT + Shift + 5		
6 DVD/ LD	SHIFT + Shift + 6		
7 DVD/ LD	SHIFT + Shift + 7		
8 DVD/ LD	SHIFT + Shift + 8		
9 DVD/ LD	SHIFT + Shift + 9		
0 DVD/ LD	SHIFT + Shift + 0		
+10/ Disc	SHIFT + Shift + Guide		
Menu DVD/ LD	Menu		

Originale	Sostituto	Originale	Sostituto
SOURCE Power	Power	CHANNEL LEVEL 0	0
MPX Pause	Pause	EFFECT +10	GUIDE Guide
CLASS Stop	Stop		
BAND Play	PLAY MODE Play		
D.ACCESS <<	<<		
>>	>>		
CHA DISPLAY I <<	I <<		
NNEL RF ATT >>I	>>I		
1	1		
DSP MODE 2	2		
MIDNIGHT 3	3		
5.1CH 4	4		
CHANNEL SELECT 5	5		
TEST TONE 6	6		
ATT 7	7		
SIGNAL SELECT 8	8		
CHANNEL LEVEL 9	9		

Originale	Sostituto
SOURCE Power VCR- DVR	Power
BAND Play VCR- DVR	Play
CHA DISPLAY I << VCR- DVR	I <<
MPX Pause VCR- DVR	Pause
NNEL + RF ATT >>I VCR- DVR	>>I
D.ACCESS << VCR- DVR	<<
>> VCR- DVR	>>
CLASS Stop VCR- DVR	Stop
1 1 VCR- DVR	1
DSP MODE 2 2 VCR- DVR	2
MIDNIGHT 3 3 VCR- DVR	3
5.1CH 4 4 VCR- DVR	4
CHANNEL SELECT 5 5 VCR- DVR	5
TEST TONE 6 6 VCR- DVR	6
ATT 7 7 VCR- DVR	7
SIGNAL SELECT 8 8 VCR- DVR	8
CHANNEL LEVEL 9 9 VCR- DVR	9

Originale	Sostituto
CHANNEL LEVEL 0 0 VCR- DVR	0
EFFECT + DISC Disc VCR- DVR	FAV PRE-CH Pre Ch
CD CD	D Blue
SOURCE Power CD	SHIFT + Shift + Power
CLASS Stop CD	SHIFT + Shift + Stop
MPX Pause CD	SHIFT + Shift + Pause
BAND Play CD	SHIFT + PLAY MODE Shift + Play
NNEL + RF ATT >>I CD	SHIFT + Shift + >>I
>> CD	SHIFT + Shift + >>
CHA DISPLAY I << CD	SHIFT + Shift + I <<
D.ACCESS << CD	SHIFT + Shift + <<