Originale		Sostituto	
	Power Tv		Power
AV	Av Tv	TIMER AV	AV
MENU	Menu Tv	TOP MENU MENU	Menu
	Up Tv		Up
	Down Tv		Down
	Left Tv		Left
	Right Tv		Right
OK	Ok Tv	OK	Ok
INFO	Info Tv	DISPLAY INFO	Info
EXIT	Exit Tv	CLEAR EXIT	Exit
	Red Tv	A	Red
	Green Tv	B	Green
	Yellow Tv	C	Yellow
	Blue Tv	D	Blue
+ VOL	Vol + Tv	+ VOL	Vol +
VOL −	Vol - Tv	VOL −	Vol -
	Mute Tv	MUTE	Mute

Originale		Sostituto	
P<P	Back Tv	RETURN BACK	Back
+ CH	Ch+ Tv	+ CH	Ch +
CH −	Ch- Tv	CH −	Ch -
▼P[≡]	▼P[≡] Tv		I <<
▲P[ ]	▲P[ ] Tv		>>I
	<< Tv		<<
	>> Tv		>>
	Stop Tv		Stop
	Play Tv	PLAY MODE	Play
1	1 Tv	1	1
2	2 Tv	2	2
3	3 Tv	3	3
4	4 Tv	4	4
5	5 Tv	5	5
6	6 Tv	6	6
7	7 Tv	7	7
8	8 Tv	8	8

Originale	Sostituto
9 Tv	9
0 Tv	0
Text Tv	Text
#Help Tv	Pre Ch
▼P [≡] Tv2	Shift + I <<
▲P [ ] Tv2	Shift + >>I
Rec Tv2	Shift + Rec
Play Tv2	Shift + Play
Av Tv2	Shift + AV
<< Tv2	Shift + <<
>> Tv2	Shift + >>
Power Tv2	Shift + Power
Guide Tv2	Shift + Guide
Menu Tv2	Shift + Menu
Up Tv2	Shift + Up
Left Tv2	Shift + Left
Right Tv2	Shift + Right

Originale	Sostituto
Down Tv2	Shift + Down
Ok Tv2	Shift + Ok
Info Tv2	Shift + Info
Green Tv2	Shift + Green
Red Tv2	Shift + Red
Exit Tv2	Shift + Exit
Yellow Tv2	Shift + Yellow
Blue Tv2	Shift + Blue
Back Tv2	Shift + Back
Ch+ Tv2	Shift + Ch +
Ch- Tv2	Shift + Ch -
Stop Tv2	Shift + Stop
Pause Tv2	Shift + Pause
1 Tv2	Shift + 1
2 Tv2	Shift + 2
3 Tv2	Shift + 3
4 Tv2	Shift + 4

Originale		Sostituto		Originale	Sostituto
5	5 Tv2	SHIFT + 5	Shift + 5		
6	6 Tv2	SHIFT + 6	Shift + 6		
7	7 Tv2	SHIFT + 7	Shift + 7		
8	8 Tv2	SHIFT + 8	Shift + 8		
9	9 Tv2	SHIFT + 9	Shift + 9		
0	0 Tv2	SHIFT + 0	Shift + 0		
* TXT	Text Tv2	SHIFT + REPEAT TEXT	Shift + Text		
# HELP	#Help Tv2	SHIFT + FAV PRE-CH	Shift + Pre Ch		

Originale	Sostituto
Power DVD	Power
AV DVD/DVR	AV
Guide DVD/DVR	Guide
Menu DVD/DVR	Menu
Info DVD/DVR	Info
Exit DVD/DVR	Exit
Up DVD/DVR	Up
Down DVD/DVR	Down
Left DVD/DVR	Left
Right DVD/DVR	Right
Ok DVD/DVR	Ok
Red DVD/DVR	Red
Green DVD/DVR	Green
Yellow	Yellow
Blue DVD/DVR	Blue
Vol + DVD/DVR	Vol +
Vol - DVD/DVR	Vol -

Originale	Sostituto
Mute DVD/DVR	Mute
Back DVD/DVR	Back
Ch+ DVD/DVR	Ch +
▼P[≡] DVD/DVR	I <<
Ch- DVD/DVR	Ch -
▲P[ ] DVD/DVR	>>I
<< DVD/DVR	<<
>> DVD/DVR	>>
Play DVD/DVR	Play
Pause DVD/DVR	Pause
Stop DVD/DVR	Stop
Rec DVD/DVR	Rec
1 DVD/DVR	1
2 DVD/DVR	2
3 DVD/DVR	3
4 DVD/DVR	4
5 DVD/DVR	5

Originale	Sostituto	Originale	Sostituto
6 DVD/ DVR	6		
7 DVD/ DVR	7		
8 DVD/ DVR	8		
9 DVD/ DVR	9		
0 DVD/ DVR	0		
Text DVD/ DVR	Text		
#Help DVD/ DVR	Pre Ch		
Power DVR	SHIFT + Power		

Originale	Sostituto
Power	Power
Menu	Menu
Guide	Guide
AV SAT/CABLE	AV
Up SAT/CABLE	Up
Down	Down
Left SAT/CABLE	Left
Right	Right
Ok SAT/CABLE	Ok
Info SAT/CABLE	Info
Exit SAT/CABLE	Exit
Red SAT/CABLE	Red
Green	Green
Yellow SAT/CABLE	Yellow
Blue SAT/CABLE	Blue
Vol +	Vol +
Vol - SAT/CABLE	Vol -

Originale	Sostituto
Mute	Mute
Back	Back
Ch+ SAT/CABLE	Ch +
Ch- SAT/CABLE	Ch -
<< SAT/CABLE	<<
>> SAT/CABLE	>>
Stop SAT/CABLE	Stop
Rec SAT/CABLE	Rec
Play SAT/CABLE	Play
Pause	Pause
1 SAT/CABLE	1
2 SAT/CABLE	2
3 SAT/CABLE	3
4 SAT/CABLE	4
5 SAT/CABLE	5
6 SAT/CABLE	6
7 SAT/CABLE	7

Originale		Sostituto	
8	8 SAT/ CABLE	8	8
9	9 SAT/ CABLE	9	9
0	0 SAT/ CABLE	0	0
# HELP	#Help	FAV PRE-CH	Pre Ch
* TXT	Text SAT/ CABLE	REPEAT TEXT	Text

Originale	Sostituto

Originale	Sostituto
Power DVBT	Power
Guide DVBT	Guide
Menu DVBT	Menu
Up DVBT	Up
Down DVBT	Down
Left DVBT	Left
Right DVBT	Right
Ok DVBT	Ok
Info DVBT	Info
Red DVBT	Red
Green DVBT	Green
Yellow DVBT	Yellow
Blue DVBT	Blue
Vol + DVBT	Vol +
Vol - DVBT	Vol -
Mute DVBT	Mute
Back DVBT	Back

Originale	Sostituto
Ch+ DVBT	Ch +
Ch- DVBT	Ch -
Pause DVBT	Pause
1 DVBT	1
2 DVBT	2
3 DVBT	3
4 DVBT	4
5 DVBT	5
6 DVBT	6
7 DVBT	7
8 DVBT	8
9 DVBT	9
0 DVBT	0
Power VCR	Shift + Power
Av VCR	AV
<< VCR	<<
Stop VCR	Stop

Originale	Sostituto
>> VCR	>>
Play VCR	PLAY MODE Play
Rec VCR	REC MODE Rec
Pause VCR	SHIFT + Shift + Pause
Guide VCR	SHIFT + GUIDE Shift + Guide
Menu VCR	SHIFT + TOP MENU MENU Shift + Menu
Up VCR	SHIFT + Shift + Up
Down VCR	SHIFT + Shift + Down
Left VCR	SHIFT + Shift + Left
Right VCR	SHIFT + Shift + Right
Ok VCR	SHIFT + OK Shift + Ok
Info VCR	SHIFT + DISPLAY INFO Shift + Info
Exit VCR	CLEAR EXIT Exit
Red VCR	SHIFT + A Shift + Red
Green VCR	SHIFT + B Shift + Green
Yellow VCR	SHIFT + C Shift + Yellow
Blue VCR	SHIFT + D Shift + Blue

Originale	Sostituto
P-P Back VCR	SHIFT + RETURN BACK Shift + Back
+ CH Ch+ VCR	SHIFT + + CH Shift + Ch +
CH – Ch- VCR	SHIFT + CH – Shift + Ch -
1 VCR	SHIFT + 1 Shift + 1
2 VCR	SHIFT + 2 Shift + 2
3 VCR	SHIFT + 3 Shift + 3
4 VCR	SHIFT + 4 Shift + 4
5 VCR	SHIFT + 5 Shift + 5
6 VCR	SHIFT + 6 Shift + 6
7 VCR	SHIFT + 7 Shift + 7
8 VCR	SHIFT + 8 Shift + 8
9 VCR	SHIFT + 9 Shift + 9
0 VCR	SHIFT + 0 Shift + 0
* TXT Text VCR	REPEAT TEXT Text
# HELP #Help VCR	FAV PRE-CH Pre Ch