Originale		Sostituto	
ON/STAND-BY	On/Standby	Power	
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PLAY MODE	Play Mode	SLOW	Play / Slow
0	0	HDMI-SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
DISPLAY(TV OUT) iPOD	iPOD Display(Tv Out)	PROGRAM TV/RADIO	TV/Radio /
MENU	iPod Menu	HOME MENU	Menu / Home
▶/II	iPod Play/Pause	STEP-FREEZE II	Pause / Step / Freeze

Originale		Sostituto	
DISPLAY CD/USB	CD/USB Display	SHIFT + MEDIA DISPLAY	Shift + Display / Media
■	CD/USB Stop	HOLD ■	Stop / Hold
▶/II	CD/USB	SHIFT + SLOW ▶	Shift + Play /
BASS/TREBLE	Bass/Treble	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
EQUALIZER MODE	Equalizer Mode	TITLE SOUND	Sound / Title
X-BASS	X-Bass	EQ SUBTITLE	Subtitle / EQ
MEMORY	Memory	LIST SMART	Smart / List
VOLUME +	Vol +	+ VOL	Vol +
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
CLEAR/DIMMER	Clear/Dimmer	CLEAR EXIT CANCEL	Exit / Cancel / Clear
–	Vol -	VOL –	Vol -
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FOLDER	Folder	OPT-TOOLS SETUP	Setup / OPT /
TUNING ▲	Up/Tuning	▲	Up
^	Preset Up	SHIFT + PRESET+ ▶▶I	Shift + >>I / Preset+
I◀◀	I<<	PRESET- I◀◀	I<< / Preset-
ENTER	Enter	OK	OK

Originale	Sostituto	Originale	Sostituto
>>I	PRESET+ >>I / Preset +		
Demo	TOP MENU D.MENU D. Menu / Top		
Down/ Tuning	Down		
Preset Down	SHIFT + PRESET- Shift + I<< / Preset-		
iPod	GOTO TEXT Text / Goto		
Tuner (Band)	SHIFT + TUNER 6 Shift + 6		
CD	SHIFT + CD - STB 3 Shift + 3		
ASPM RDS	FORMAT PICTURE Picture / Format		
USB	SHIFT + USB 8 Shift + 8		
PTY RDS	SIZE ZOOM Zoom / Size		
Audio In	LANG I/II AUDIO Audio / Lang I/II		
Display RDS	MEDIA DISPLAY Display / Media		