Originale		Sostituto	
STANDBY	Standby		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
P.MODE	P Mode	FORMAT PICTURE	Picture / Format
S.MODE	S Mode	TITLE SOUND	Sound / Title
FREEZE	Freeze	STEP-FREEZE	Pause / Step / Freeze
TXT	TXT	GOTO TEXT	Text / Goto
FAV.LIST MIX	Mix / Fav List	PC FAV MARKER	Fav / Marker / PC
SUBTITLE SIZE	Size / Subtitl	SIZE ZOOM	Zoom / Size
AUDIO CANCEL	Cancel / Audio	SHIFT +	CLEAR EXIT CANCEL Shift + Exit / Cancel / Clear
RECORD	Record	REC MODE	Rec / Rec Mode
INDEX	<< / Index	TUNE-	<< / Tune-
HOLD	>> / Hold	TUNE+	>> / Tune+
REVEAL	I<< / Reveal	PRESET-	I<< / Preset-

Originale		Sostituto	
SUBPAGE	>>I / Subpage	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
TIMESHIFT	Play/Pause / Timeshift	SLOW	Play / Slow
TIMESHIFT	Play/Pause / Timeshift	SHIFT + SLOW	Shift + Play /
	Down		Down
EPG	Stop / EPG	SHIFT + HOLD	Shift + Stop /
EPG	Stop / EPG	HOLD	Stop / Hold
VOL +	Vol +	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH	CH +	CH PAGE +	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
TV/RADIO	TV / Radio	PROGRAM TV/RADIO	TV/Radio / Program

Originale		Sostituto		Originale	Sostituto
CH	CH -	CH PAGE	CH- / Page-		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
0	0	HDMI - SAT 0	0		
RECALL	Recall	RETURN BACK	Back / Return		