Originale		Sostituto	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ON/STANDBY	On/Standby		Power
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
DVD	DVD	DVD 2	2
Blu-ray	Blu-ray	VIDEO 4	4
GAME	Game	PC FAV MARKER	Fav / Marker / PC
AUX	AUX	AUX - HDD 7	7
MEDIA PLAYER	Media Player	MEDIA DISPLAY	Display / Media
TV AUDIO	TV Audio	TV 1	1
CD	CD	CD - STB 3	3
TUNER	Tuner	TUNER 6	6
iPod /USB	iPod/USB	USB 8	8
PHONO	Phono	-/-- GUIDE EPG	Guide / EPG / -/--
M-XPort	M-XPort	TAPE 5	5
NETWORK	Network	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	LIST SMART	Smart / List
CH / PAGE	CH+	+ CH PAGE	CH+ / Page+

Originale		Sostituto	
VOLUME	Vol +	+ VOL	Vol +
CH / PAGE	CH-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Vol -	VOL –	Vol -
INFO	Info	ANGLE INFO	Info / Angle
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
OPTION	Option	HOME MENU	Menu / Home
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
TUNE –	I<<Tune-	PRESET-	I<< / Preset-
TUNE –	I<<Tune-	TUNE-	<< / Tune-
►/II	Play / Pause	SLOW ►	Play / Slow

Originale	Sostituto	Originale	Sostituto
Play / Pause	Pause / Step / Freeze		
>>I / Tune+	>> / Tune+		
>>I / Tune+	>>I / Preset+		
Favorite Station	Sound / Title		
Favorite Station	Audio / Lang I/II		
Favorite Station	Subtitle / EQ		
Red/Movie	Red / Netflix / Search		
Green/Music	Green / APP / Repeat		
Blue/Game	Blue / Prime Video / Random		
Yellow/Pure	Yellow / YouTube / Repeat		

Originale		Sostituto	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ON/STANDBY	On/Standby		Power
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
DVD	DVD	DVD 2	2
Blu-ray	Blu-ray	VIDEO 4	4
GAME	Game	PC FAV MARKER	Fav / Marker / PC
AUX	AUX	AUX - HDD 7	7
MEDIA PLAYER	Media Player	MEDIA DISPLAY	Display / Media
TV AUDIO	TV Audio	TV 1	1
CD	CD	CD - STB 3	3
TUNER	Tuner	TUNER 6	6
iPod /USB	iPod/USB	USB 8	8
PHONO	Phono	-/-- GUIDE EPG	Guide / EPG / -/--
M-XPort	M-XPort	TAPE 5	5
NETWORK	Network	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	LIST SMART	Smart / List
CH / PAGE	CH+	+ CH PAGE	CH+ / Page+

Originale		Sostituto	
VOLUME	Vol +	+ VOL	Vol +
CH / PAGE	CH-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Vol -	VOL –	Vol -
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
OPTION	Option	HOME MENU	Menu / Home
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE –	I<<Tune-	PRESET-	I<< / Preset-
TUNE –	I<<Tune-	TUNE-	<< / Tune-
▶/II	Play / Pause	SLOW ▶	Play / Slow
▶/II	Play / Pause	STEP - FREEZE II	Pause / Step / Freeze
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+

Originale	Sostituto	Originale	Sostituto
TUNE+ >>I / Tune+	TUNE+ >> / Tune+		
1 Favorite Station	TITLE SOUND Sound / Title		
2 Favorite Station	LANG I/II AUDIO Audio / Lang I/II		
3 Favorite Station	EQ SUBTITLE Subtitle / EQ		