Originale		Sostituto	
POWER	Power	POWER	Power
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FAV	FAV	FAV PRE-CH	Pre Ch
SUB-T	SUB-T	AD SUBT	Subt
OPTION	Option	SETTINGS OPT	Options
SETUP	Setup	TOP MENU MENU	Menu
▲	Up	▲	Up

Originale		Sostituto	
▶	Right	▶	Right
▼	Down	▼	Down
◀	Left	◀	Left
OK	OK	OK	Ok
EXIT	Exit	CLEAR EXIT	Exit
HOME	Home	HOME SMART	Smart
◀◀	<<	<<	<<
▶▶	>>	>>	>>
▶II	Play / Pause	PLAY MODE ▶	Play
▶II	Play / Pause	II	Pause
■	Stop	■	Stop
TV system	TV System	APP MEDIA	Media
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
EDIT	Edit	E-MANUAL D.MENU	D. Menu
AUDIO	Audio	SOUND DUAL	Dual
INFO	Info	DISPLAY INFO	Info

Originale	Sostituto	Originale	Sostituto
I << / P +	Ch +		
I << / P +	I <<		
>>I / P -	Ch -		
>>I / P -	>>I		
Repeat	Text		
Got o	Gui de		
Zoom	Ej ect		