Originale		Sostituto	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play / Pause	SLOW	Play / Slow
STEP	Step II >	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REV	<< Rev	TUNE-	<< / Tune-
FWD	Fwd >>	TUNE+	>> / Tune+
PREV	I << Prev	PRESET-	I << / Preset-
NEXT	Next >>I	PRESET+	>>I / Preset+
TITLE	Title	TITLE SOUND	Sound / Title
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround
V-MODE	V-Mode	FORMAT PICTURE	Picture / Format
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
TV-MODE	TV-Mode	TOP MENU D.MENU	D.Menu / Top Menu

Originale		Sostituto	
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
N/P	N / P	GOTO TEXT	Text / Goto
USB/CARD	USB / Card	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOL+	Vol +	VOL +	Vol +
PBC	PBC	LIST SMART	Smart / List
VOL-	Vol -	VOL -	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2

Originale		Sostituto	
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10+	10+	GUIDE EPG	Guide / EPG / -/--
0	0	0	0
L/R	L / R	FAV MARKER	Fav / Marker / PC
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
SLOW	Slow	SHIFT + SLOW	Shift + Play /

Originale	Sostituto