Originale		Sostituto	
	Power		Power
	Text / Display	REPEAT TEXT	Text
CALL	Call / Index	DISPLAY INFO	Info
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Recall	FAV PRE-CH	Pre Ch
	Input	TIMER AV	AV
MENU DVD MENU	Menu / DVD	TOP MENU MENU	Menu
→| [/] |←		ECO 3D	3D

Originale		Sostituto	
	Aspect	PICTURE FORMAT	Format
EXIT	Exit	CLEAR EXIT	Exit
P▲	Up / P+		Up
P▲	Up / P+	+ CH	Ch +
P▼	Down / P-		Down
P▼	Down / P-	CH −	Ch -
	Right / Vol +		Right
	Right / Vol +	+ VOL	Vol +
	Left / Vol -		Left
	Left / Vol -	VOL −	Vol -
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
I/II	I/II	SOUND DUAL	Dual
	Audio	SHIFT + SOUND DUAL	Shift + Dual

Originale		Sostituto		Originale		Sostituto	
	Mute	MUTE	Mute				
	Play / Reveal	HOME SMART	Smart				
	Stop / Hold		Stop				
	Play / Reveal	PLAY MODE	Play				
	<< / Size		<<				
	>> / [⏻] / [⏻/X]		>>				

Originale	Sostituto	Originale	Sostituto
Power	Power		
Menu DVD	Menu		
Up	Up		
Down	Down		
Right	Right		
Left	Left		
OK	Ok		
Pause	Pause		
Play	Play		
<<	<<		
>>	>>		
Open/Close	Eject		
Stop	Stop		
I<<	I<<		
>>I	>>I		

Originale	Sostituto	Originale	Sostituto
Power	Power		
Pause	Pause		
Play	Play		
<<	<<		
>>	>>		
Eject	Eject		
Stop	Stop		
I <<	I <<		
>>I	>>I		