Originale		Sostituto	
DVD POWER	DVD Power	Power	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
OPEN/CLOSE	Open / Close	CLEAR EXIT	Exit
SET UP	Setup	SETTINGS OPT	Options
ZOOM	Zoom	ZOOM	Eject
3D SOUND	3D Sound	ECO 3D	3D
BOOKMARK	Bookmark	FAV PRE-CH	Pre Ch
VOLUME CON.	Volume Con.	-/-- GUIDE	Guide

Originale		Sostituto	
<<	<<	<<	<<
>>	>>	>>	>>
Stop	Stop	Stop	Stop
Play / Pause	Play / Pause	PLAY MODE	Play
Play / Pause	Play / Pause	II	Pause
I <<	I <<	I <<	I <<
>>I	>>I	>>I	>>I
Return	Return	RETURN BACK	Back
STEP	Step	SHIFT + II	Shift + Pause
CLEAR	Clear	SHIFT + CLEAR EXIT	Shift + Exit
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
TOP MENU	Top Menu	E-MANUAL D.MENU	D. Menu
DISPLAY	Display	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok

Originale	Sostituto	Originale	Sostituto
Right	Right		
Down	Down		
Audio	SOUND DUAL	Dual	
Sub Title	AD SUBT	Subt	
Angle	PICTURE FORMAT	Format	
Repeat	REPEAT TEXT	Text	
Repeat A-B	SHIFT + REPEAT TEXT	Shift + Text	