Originale		Sostituto	
POWER	Power		Power
TV	TV	LIST SMART	Smart / List
TV	TV	SHIFT + TV 1	Shift + 1
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
-/--	-/--	SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
PRE-CH	PRE-CH	RETURN BACK	Back / Return
TV/DTV	TV/DTV	PROGRAM TV/RADIO	TV/Radio / Program

Originale		Sostituto	
CH MGR	CH MGR	MEDIA DISPLAY	Display / Media
D.MENU	D.Menu	TOP MENU D.MENU	D.Menu / Top
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
REW	<< REW	TUNE-	<< / Tune-
REW	<< REW	PRESET-	I<< / Preset-
STOP	Stop	HOLD	Stop / Hold
	Vol +	VOL +	Vol +
FF	>> FF	PRESET+	>>I / Preset+
FF	>> FF	TUNE+	>> / Tune+
PLAY/PAUSE	Play / Pause	SLOW	Play / Slow
PLAY/PAUSE	Play / Pause	STEP-FREEZE	Pause / Step / Freeze
	Vol -	VOL -	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	CH PAGE +	CH+ / Page+
	P-	CH PAGE -	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Originale		Sostituto	
ENTER /OK	Enter / OK	OK	OK
	Up		Up
	Left		Left
	Right		Right
	Down		Down
TEXT/MIX	Text / Mix	GOTO TEXT	Text / Goto
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
INFO	Info	ANGLE INFO	Info / Angle
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
PIP	PIP	OPT-TOOLS SETUP	Setup / OPT /
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
S.MODE	S. Mode	TITLE SOUND	Sound / Title
P.SIZE	P. Size	SIZE ZOOM	Zoom / Size
SRS	SRS	SURROUND	Eject / Surround

Originale		Sostituto	
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
DUAL I-II	Dual I-II	LANG I/II AUDIO	Audio / Lang I/II
STILL	Still	SHIFT + STEP-FREEZE	Shift + Pause / Step /

Originale		Sostituto	
DVD	DVD	LIST SMART	Smart / List
DVD	DVD	SHIFT + DVD 2	Shift + 2
POWER	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
REW	<< REW	TUNE-	<< / Tune-
REW	<< REW	PRESET-	I << / Preset-
PLAY/PAUSE	Play / Pause	SLOW	Play / Slow
PLAY/PAUSE	Play / Pause	STEP-FREEZE	Pause / Step / Freeze

Originale		Sostituto	
FF	>> FF	PRESET+	>>I / Preset+
FF	>> FF	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
ENTER /OK	Enter / OK	OK	OK
	Up		Up
	Left		Left
	Right		Right
	Down		Down
INFO	Info	ANGLE INFO	Info / Angle

Originale		Sostituto	
STB	STB	LIST SMART	Smart / List
STB	STB	SHIFT + CD-STB 3	Shift + 3
POWER	Power		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
PRE-CH	PRE-CH	RETURN BACK	Back / Return
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
REW	<< REW	TUNE-	<< / Tune-

Originale		Sostituto	
REW	<< REW	PRESET-	I<< / Preset-
PLAY/PAUSE	Play / Pause	STEP-FREEZE	Pause / Step / Freeze
FF	>> FF	PRESET+	>>I / Preset+
PLAY/PAUSE	Play / Pause	SLOW	Play / Slow
FF	>> FF	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	CH PAGE +	CH+ / Page+
	P-	CH PAGE -	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
ENTER /OK	Enter / OK	OK	OK
	Left		Left
	Right		Right

Originale	Sostituto	Originale	Sostituto
Down	Down		
Gui de	Gui de / EPG / -/--		
Info	Info / Angle		

Originale		Sostituto	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
POWER	CABLE Power		Power
CABLE	CABLE	LIST SMART	Smart / List
VCR	VCR	MEDIA DISPLAY	Display / Media
1	CABLE 1	TV 1	1
2	CABLE 2	DVD 2	2
3	CABLE 3	CD-STB 3	3
4	CABLE 4	VIDEO 4	4
5	CABLE 5	TAPE 5	5
6	CABLE 6	TUNER 6	6
7	CABLE 7	AUX-HDD 7	7
8	CABLE 8	USB 8	8
9	CABLE 9	BLUETOOTH 9	9
0	CABLE 0	HDMI-SAT 0	0
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
P	CABLE P-	CH PAGE −	CH- / Page-

Originale		Sostituto	
	CABLE P+	+ CH PAGE	CH+ / Page+
POWER	VCR Power	SHIFT +	Shift + Power
MENU	VCR Menu	HOME MENU	Menu / Home
EXIT	VCR Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
1	VCR 1	SHIFT + TV 1	Shift + 1
2	VCR 2	SHIFT + DVD 2	Shift + 2
3	VCR 3	SHIFT + CD-STB 3	Shift + 3
4	VCR 4	SHIFT + VIDEO 4	Shift + 4
5	VCR 5	SHIFT + TAPE 5	Shift + 5
6	VCR 6	SHIFT + TUNER 6	Shift + 6
7	VCR 7	SHIFT + AUX-HDD 7	Shift + 7
8	VCR 8	SHIFT + USB 8	Shift + 8
9	VCR 9	SHIFT + BLUETOOTH 9	Shift + 9
0	VCR 0	SHIFT + HDMI-SAT 0	Shift + 0
P	VCR P+	SHIFT + + CH PAGE	Shift + CH+ /
	VCR P-	SHIFT + CH PAGE −	Shift + CH- /
	VCR Up		Up

Originale	Sostituto	Originale	Sostituto
VCR Left	Left		
VCR Enter/OK	OK		
VCR Right	Right		
VCR Down	Down		
VCR Info	Info / Angle		
VCR Stop	Stop / Hold		
VCR << REW	<< / Tune-		
VCR << REW	I<< / Preset-		
VCR Play/Pause	Play / Slow		
VCR Play/Pause	Pause / Step / Freeze		
VCR >> FF	>> / Tune+		
VCR >> FF	>>I / Preset+		