Originale	Sostituto	Originale	Sostituto
AVR Power On	Power	OK	OK
Mute	Mute / Dimmer	Right	Right
Play	Play / Slow	Back/Exit	Exit / Cancel / Clear
Pause	Pause / Step / Freeze	Down	Down
Stop	Stop / Hold	Last	Back / Return
<<	<< / Tune-	Vol +	Vol +
>>	>> / Tune+	AVR	Smart / List
I <<	I << / Preset-	CH/Page Up	CH+ / Page+
>>I	>>I / Preset+	Vol -	Vol -
Audio Effects	Audio / Lang I/II	CH/Page Down	CH- / Page-
Surround Modes	Eject / Surround	1	1
Video Modes	Picture / Format	2	2
Sleep	Sleep / Timer	3	3
Menu	Menu / Home	4	4
Up	Up	5	5
Info	Info / Angle	6	6
Left	Left	7	7

Originale	Sostituto	Originale	Sostituto
8	USB 8 8	Cabl e/ Sat	SHIFT + HDMI - SAT 0 Shi f t + 0
9	BLUETOOTH 9 9		
0	HDMI - SAT 0 0		
Red	NETFLIX SEARCH Red / Netflix / Search		
Gr een	APP REPEAT Green / APP / Repeat		
Yel l ow	YouTube REPEAT A-B Yel l ow / YouTube / Repeat		
Bl ue	Prime Video RANDOM Bl ue / Pri me Vi deo / Random		
AVR Power Off	SHIFT + Power Shi f t + Power		
Tv	SHIFT + TV 1 Shi f t + 1		
Bl u-r ay	SHIFT + DVD 2 Shi f t + 2		
DVR	SHIFT + CD - STB 3 Shi f t + 3		
i Pod	SHIFT + VIDEO 4 Shi f t + 4		
Net wor k	SHIFT + TAPE 5 Shi f t + 5		
Radi o	SHIFT + TUNER 6 Shi f t + 6		
AUX	SHIFT + AUX - HDD 7 Shi f t + 7		
Game	SHIFT + USB 8 Shi f t + 8		
Medi a Ser ver	SHIFT + BLUETOOTH 9 Shi f t + 9		

Originale	Sostituto		Originale	Sostituto	
1	TV 1	1	Mute	DIMMER MUTE	Mute / Dimmer
DVR	MEDIA DISPLAY	Display / Media	Vol +	+ VOL	Vol +
DVR Power On		Power	Vol -	VOL −	Vol -
2	DVD 2	2	CH/Page Up	+ CH PAGE	CH+ / Page+
3	CD - STB 3	3	CH/Page Down	CH PAGE −	CH- / Page-
4	VIDEO 4	4			
5	TAPE 5	5			
6	TUNER 6	6			
7	AUX - HDD 7	7			
8	USB 8	8			
9	BLUETOOTH 9	9			
0	HDMI - SAT 0	0			
Menu	HOME MENU	Menu / Home			
Up		Up			
Down		Down			
Right		Right			
Left		Left			

Originale	Sostituto	Originale	Sostituto
Bluray Power	Power	Down	Down
Mute	Mute / Dimmer	Last	Back / Return
Play	Play / Slow	Vol +	Vol +
Pause	Pause / Step / Freeze	Vol -	Vol -
Stop	Stop / Hold	Blu-ray	Display / Media
Rec	Rec / Rec Mode	1	1
<<	<< / Tune-	2	2
>>	>> / Tune+	3	3
I <<	I << / Preset-	4	4
>>I	>>I / Preset+	5	5
Disc Menu	D. Menu / Top	6	6
Menu	Menu / Home	7	7
Up	Up	8	8
Left	Left	9	9
OK	OK	0	0
Right	Right	Red	Red / Netflix / Search
Back/Exit	Exit / Cancel / Clear	Green	Green / APP / Repeat

Originale	Sostituto	Originale	Sostituto
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM Blue / Prime Video / Random		
Bluray Power Off	SHIFT + Power Shift + Power		

Originale	Sostituto	Originale	Sostituto
AVR Power On	Power	Right	Right
AVR Power Off	Shift + Power	Left	Left
1	1	OK	OK
2	2	Red	Red / Netflix / Search
3	3	Green	Green / APP / Repeat
4	4	Yellow	Yellow / YouTube / Repeat
5	5	Blue	Blue / Prime Video / Random
6	6	Vol +	Vol +
7	7	Vol -	Vol -
8	8	Mute	Mute / Dimmer
9	9	CH/Page Up	CH+ / Page+
0	0	CH/Page Down	CH- / Page-
Menu	Menu / Home	Pause	Pause / Step / Freeze
Back/Exit	Exit / Cancel / Clear	<<	<< / Preset-
Last	Back / Return	>>I	>>I / Preset+
Up	Up	Play	Play / Slow
Down	Down	<<	<< / Tune-

Originale	Sostituto
>>	>> / Tune+
Stop	Stop / Hold
Rec	Rec / Rec Mode
Info	Info / Angle
Sleep	Sleep / Timer
AVR	Smart / List
Audio Effects	Audio / Lang I/II
Video Modes	Picture / Format
Surround Modes	Eject / Surround
Cable/SAT	Shift + 0
Blu-ray	Shift + 2
iPod	Shift + 4
Radio	Shift + 6
TV	Shift + 1
AUX	Shift + 7
DVR	Shift + 3
Game	Shift + 8

Originale	Sostituto
Media Server	Shift + 9
Network	Shift + 5