Originale		Sostituto	
STANDBY	Power		Power
MUTE	Mute	MUTE	Mute
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	<<		<<
	>>		>>
	I <<		I <<
	>>I		>>I
RECORD	Record	REC MODE	Rec
OK	OK	OK	Ok
CH+	Up		Up
CH+	CH+	CH +	Ch +
CH-	CH-	CH -	Ch -
CH-	Down		Down
VOL +	Right		Right
VOL +	Vol +	VOL +	Vol +

Originale		Sostituto	
VOL -	Left		Left
VOL -	Vol -	VOL -	Vol -
INFO	Info	DISPLAY INFO	Info
RETURN/EXIT	Return/Exit	RETURN BACK	Back
SETUP	Setup	SETTINGS OPT	Options
DVD/DVB	DVD/DVB	HOME SMART	Smart
GOTO	Goto	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Originale	Sostituto	Originale	Sostituto
PROG Prog	PROG SLEEP Sleep		
TITLE/TTX Title/TTX	REPEAT TEXT Text		
AUDIO Audio	SOUND DUAL Dual		
SUBTITLE Subtitle	AD SUBT Subt		
SLOW Slow	ECO 3D 3D		
EPG EPG	-/-- GUIDE Guide		
TV/RADIO Tv/Radio	SEARCH TV/R TV/R		
OPEN/CLOSE Open/Close	ZOOM Eject		
FAVORITE Favorite	FAV PRE-CH Pre Ch		
REPEAT Red/Repeat	A Red		
REPEAT Red/Repeat	SHIFT + REPEAT TEXT Shift + Text		
A-B Green/A-B	B Green		
MENU Yellow/Menu	C Yellow		
MENU Yellow/Menu	TOP MENU MENU Menu		
ANGLE Blue/Angle	D Blue		
P/N PN	TIMER AV AV		