Originale		Sostituto	
	Power		Power
	Eject	ZOOM	Eject
	Mute	MUTE	Mute
	[ ]	AD SUBT	Subt
	[≡]	REPEAT TEXT	Text
	Source	TIMER AV	AV
ON TIMER	On Timer	SEARCH TV/R	TV/R
SLEEP	Sleep	PROG SLEEP	Sleep
MENU	Menu	TOP MENU MENU	Menu
OK	OK	OK	Ok
	←	RETURN BACK	Back
	Up/+		Up
	Down/-		Down
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4

Originale		Sostituto	
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/-- GUIDE	Guide
[i+]	[i+]	DISPLAY INFO	Info
SHOW VIEW	Show View	ECO 3D	3D
ONCE	Once	HOME SMART	Smart
DAILY	Daily	APP MEDIA	Media
WEEKLY	Weekly	SETTINGS OPT	Options
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
PROGR +	Prog+	CH +	Ch +
	Prog-	CH -	Ch -
	Red	A	Red

Originale	Sostituto	Originale	Sostituto
Green	Green		
Yellow	Yellow		
Blue	Blue		
REC Rec	REC MODE Rec		
TIMER ON SCREEN Timer	DISC NAV LIST List		
ON/OFF Timer Rec On/Off	E-MANUAL D.MENU D. Menu		
CLEAR Clear	CLEAR EXIT Exit		
QUICK TIMER Quick Timer	SOUND DUAL Dual		
PAUSE Pause	Pause		
COUNTER RESET Reset Counter	PICTURE FORMAT Format		
PLAY Play	PLAY MODE Play		
STOP Stop	Stop		
FF >>	>>		
REW <<	<<		