Originale		Sostituto	
	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
SUBTITLE POSITION MEMORY	Subtitle	EQ SUBTITLE	Subtitle / EQ
SUBTITLE POSITION MEMORY	Position	NETFLIX SEARCH	Red / Netflix / Search
SETUP GROUP	Group	APP REPEAT	Green / APP / Repeat
SETUP GROUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
DISC	Disc	REC MODE	Rec / Rec Mode
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
≥10/-/--	>=10 / -/--	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Originale		Sostituto	
0	0	HDMI-SAT 0	0
PRO LOGIC	DD Pro Logic	LIST SMART	Smart / List
CH SELECT TEST	CH Select	PC FAV MARKER	Fav / Marker / PC
CH SELECT TEST	Test	GOTO TEXT	Text / Goto
SUPER SRND	Super SRND	SURROUND	Eject / Surround
TOP MENU EQ DIRECT NAVIGATOR	Top Menu / Direct Navigator	TOP MENU D.MENU	D.Menu / Top
TOP MENU EQ DIRECT NAVIGATOR	EQ	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ
	Up		Up
MENU SUPER SOUND EQ PLAY LIST	Menu/Playlist	HOME MENU	Menu / Home
MENU SUPER SOUND EQ PLAY LIST	Super Surround	TITLE SOUND	Sound / Title
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
S.3D AI EQ DISPLAY	Display	MEDIA DISPLAY	Display / Media
S.3D AI EQ DISPLAY	Super 3D AI EQ	FORMAT PICTURE	Picture / Format
	Down		Down
AV EFFECT RETURN	AV Effect	RDS AV INPUT	AV / Input / RDS

Originale		Sostituto		Originale		Sostituto	
RETURN	Return	RETURN BACK	Back / Return	SKIP	Skip >>I	PRESET+	>>I / Preset+
VCR(EXT)/VDP(AUX)	VCR (Ext) / VDP (Aux)	SHIFT + VIDEO 4	Shift + 4	VOLUME –	Volume-	VOL –	Vol -
TAPE/DECK 1/2	TAPE / Deck 1/2	SHIFT + TAPE 5	Shift + 5	VOLUME +	Volume+	+ VOL	Vol +
DVD	DVD	SHIFT + DVD 2	Shift + 2				
TUNER/BAND	TUNER / BAND	SHIFT + TUNER 6	Shift + 6				
CANCEL PLAY MODE	Play Mode	SHIFT + SLOW ▶	Shift + Play /				
CANCEL PLAY MODE	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
◀/II	Rev. Play / Pause	STEP-FREEZE II	Pause / Step / Freeze				
■	Stop	HOLD ■	Stop / Hold				
▶	Play	SLOW ▶	Play / Slow				
MIX 2CH AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II				
MIX 2CH AUDIO	Mix 2CH	PROGRAM TV/RADIO	TV/Radio /				
DIGITAL S.WOOFER	Digital S.Woofer	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
SLOW/SEARCH ◀◀	<< Slow/Search	TUNE- ◀◀	<< / Tune-				
SLOW/SEARCH ▶▶	Slow/Search >>	TUNE+ ▶▶	>> / Tune+				
MUTING	Muting	DIMMER MUTE	Mute / Dimmer				
SKIP ◀◀	I<< Skip	PRESET- ◀◀	I<< / Preset-				