Mandis shop

RMT- 234

Originale		Sostituto	
ON	Power		Power
PROGRAM +	Program+	CH +	Ch +
PROGR	Program-	CH −	Ch -
	Rec	REC MODE	Rec
PLAY	Play	PLAY MODE	Play
FF	>>		>>
REW	<<		<<
STOP	Stop		Stop
PAUSE	Pause		Pause

Originale	Sostituto

https://remotecontrols.it/Sony/1662-879-telecomando-sostituzione-Sony-RMT-234-143852.html