Originale	Sostituto
POWER Power	Power
FUNCTION TV SOURCE Function	PROGRAM TV/RADIO TV/Radio /
Eject	SURROUND Eject / Surround
SLEEP Sleep	TIMER SLEEP Sleep / Timer
RDS DISPLAY 1 1 / RDS Displa	TV 1 1
2 2	DVD 2 2
TA 3 3 / TA	CD-STB 3 3
PTY- 4 4 / PTY -	VIDEO 4 4
PTY SEARCH 5 5 / PTY Search	TAPE 5 5
PTY+ 6 6 / PTY +	TUNER 6 6
7 7	AUX-HDD 7 7
8 8	USB 8 8
9 9	BLUETOOTH 9 9
FULL SCREEN Full Screen	SIZE ZOOM Zoom / Size
0 0	HDMI-SAT 0 0
REPEAT Repeat	SHIFT + APP REPEAT Shift + Green / APP /
I<<	PRESET- I<< / Preset-

Originale	Sostituto
>>I	PRESET+ >>I / Preset+
<<	TUNE- << / Tune-
>>	TUNE+ >> / Tune+
Stop	HOLD Stop / Hold
Play	SLOW Play / Slow
Pause	STEP-FREEZE Pause / Step / Freeze
VOL + Vol +	VOL +
MUTE Mute	DIMMER MUTE Mute / Dimmer
TUNING / CH Tuning+ / CH +	CH PAGE CH+ / Page+
VOL - Vol -	VOL -
V-SOUND V-Sound	TITLE SOUND Sound / Title
TUNING / CH Tuning- / CH -	CH PAGE CH- / Page-
DISC MENU Disc Menu	TOP MENU D.MENU D.Menu / Top
MENU Menu	HOME MENU Menu / Home
TITLE MENU POPUP Title Menu / PopUp Menu	SHIFT + HOME MENU Shift + Menu /
TOOLS Tools	OPT-TOOLS SETUP Setup / OPT /
Up	Up

Originale		Sostituto		Originale		Sostituto	
INFO	Info	ANGLE INFO	Info / Angle				
◀	Left	◀	Left				
Enter		OK	OK				
▶	Right	▶	Right				
RETURN	Return	RETURN BACK	Back / Return				
▼	Down	▼	Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
A	Red	NETFLIX SEARCH	Red / Netflix / Search				
B	Green	APP REPEAT	Green / APP / Repeat				
TUNER MEMORY C	Yellow / Tuner Memory	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
MO/ST D	Blue / Mo/St	Prime Video RANDOM	Blue / Prime Video / Random				
SMART HUB	Smart Hub	LIST SMART	Smart / List				
SEARCH	Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /				
S/W LEVEL	S/W Level	EQ SUBTITLE	Subtitle / EQ				
DSP	DSP	MEDIA DISPLAY	Display / Media				
vTuner	vTuner	GOTO TEXT	Text / Goto				

Originale	Sostituto	Originale	Sostituto
POWER — Power	Power — Power	Stop	Stop / Hold
FUNCTION TV SOURCE — TV Source	RDS AV INPUT — AV / Input / RDS	Play	Play / Slow
SLEEP — Sleep	TIMER SLEEP — Sleep / Timer	Pause	STEP-FREEZE — Pause / Step / Freeze
RDS DISPLAY 1 — 1	TV 1 — 1	VOL + — Vol +	VOL + — Vol +
2 — 2	DVD 2 — 2	MUTE — Mute	DIMMER MUTE — Mute / Dimmer
TA 3 — 3	CD-STB 3 — 3	TUNING / CH — CH+	CH PAGE + — CH+ / Page+
PTY- 4 — 4	VIDEO 4 — 4	VOL — — Vol -	VOL — — Vol -
PTY SEARCH 5 — 5	TAPE 5 — 5	TUNING / CH — CH-	CH PAGE — — CH- / Page-
PTY+ 6 — 6	TUNER 6 — 6	MENU — Menu	HOME MENU — Menu / Home
7 — 7	AUX-HDD 7 — 7	TOOLS — Tools	OPT-TOOLS SETUP — Setup / OPT /
8 — 8	USB 8 — 8	Up	Up
9 — 9	BLUETOOTH 9 — 9	INFO — Info	ANGLE INFO — Info / Angle
0 — 0	HDMI-SAT 0 — 0	Left	Left
I<< — I<<	PRESET- — I<< / Preset-	Enter	OK — OK
>>I — >>I	PRESET+ — >>I / Preset+	Right	Right
<< — <<	TUNE- — << / Tune-	RETURN — Return	RETURN BACK — Back / Return
>> — >>	TUNE+ — >> / Tune+	Down	Down

Originale		Sostituto		Originale	Sostituto
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
A	Red	NETFLIX SEARCH	Red / Netflix / Search		
B	Green	APP REPEAT	Green / APP / Repeat		
TUNER MEMORY C	Yellow/Tuner	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
MO/ST D	Blue/Mo/St	Prime Video RANDOM	Blue / Prime Video / Random		
SMART HUB	Smart HUB	LIST SMART	Smart / List		
SEARCH	Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /		