Mandis shop

42791

Originale	Sostituto
Power	Power
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Mem+	CH+ / Page+
0	0
C	Fav / Marker / PC
Mem-	CH- / Page-
Channel +	Up
People	Smart / List

Originale	Sostituto
Vol -	Vol -
Vol +	Vol +
→ ←	Guide / EPG / -/--
Channel -	Down
Bass+	Right
Treble+	>> / Tune+
Start	Menu / Home
Bass-	Left
Treble-	<< / Tune-
End	Exit / Cancel / Clear

https://remotecontrols.nl/EIS10538984-remote-control-substitute-for-EIS42791.htm